



PUMP RANGE



Industrial, Construction, Mining, Marine,
Off-Highway, Logging and more

PUMP RANGE



OUR PRODUCTION

INDUSTRIAL SPARE PARTS

CATERPILLAR®

PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION
1003259	PUMP G.	1252989	PUMP A	1670994	PUMP GP
1003414	PUMP G.	1262016	PUMP GP	1671153	PUMPGP
1006239	PUMP GP	1265918	PUMP	1687873	PUMP
1038264	PUMP G	1268227	PUMP	1712092	PUMP
1041752	PUMP GP	1291172	WATER PUMP ASSY	1727760	PUMP GP-WT
1053635	PUMP	1318239	PUMP GP-WT	1727762	PUMP GP-WT
1063927	PUMP GP-WA	1331403	PUMP GP-GE	1727763	PUMP GP-WT
1068957	OIL PUMP	1335100	PUMP GP	1727764	PUMP GP-WT
1068958	OIL PUMP	1354926	PUMP G WT	1727765	PUMP GP-WT
1070035	PUMP GP	1360529	PUMP GP	1727766	PUMP GP -WT
1078136	PUMP GP	1371296	PUMP GP	1727767	PUMP GP -WT
1150637	OIL PUMP	1371338	PUMP GP WT	1727768	PUMP GP-WA
1161980	PUMP GP	1371339	WATER PUMP	1727769	PUMP GP-WA
1171653	PUMP GP.	1392383	PUMP GP	1727771	PUMP
1186796	PUMP G.	1408068	PUMP ASS	1727772	WATER PUMP
1192924	PUMP G.	1408886	PISTON PUMP	1727775	PUMP GP-WT
1192925	PUMP G.	1427549	PUMP GP	1727776	PUMP GP-WT
1195013	PUMP GP	1439722	PUMP GP	1727778	WATER PUMP U.
1198474	PUMP G.	1453879	PUMP G. GEAR	1752382	PUMP GP-WA
1198748	PUMP GP	1477343	PUMP GP	1767000	PUMP GP-WT
1198749	PUMP G	1553609	PUMP GP-GR	1777517	PUMP GP-SL
1198752	PUMP G.	1590869	PUMP G.	1786633	PUMP AS
1198757	PUMP G.	1593137	PUMP AS-WT	1809588	PUMP GP-PS
1198760	PUMP GP	1593139	PUMP WATER	1863732	PUMP
1198761	PUMP G.	1593140	PUMP AS	1878943	PUMP
1198763	PUMP G.	1593141	PUMP AS-WT	1878982	PUMP
1198770	PUMP G.	1593142	PUMP AS	1898777	PUMP GP-GR
1208402	PUMP GP WT	1593144	PUMP	1902279	PUMP GP
1212501	PUMP GP	1593145	PUMP AS-WT	1939237	PUMP
1214313	PUMP GP	1608186	PUMP GP-WA	2004497	PUMP GP
1214512	PUMP GP	1609880	PUMP	2027676	PUMP GP-WT
1217385	PUMP GP	1614110	PUMP G.	2109097	PUMP A WT
1217739	PUMP GP	1614111	OIL PUMP	2111812	PUMP GP-WATER
1226658	PUMP GP	1614113	PUMP GP	2128176	PUMP GP-WT
1232374	PUMP GP	1615719	PUMP GP	2191964	PUMP GP
1238393	PUMP GP-WT	1616634	PUMP GP-PS	2223769	PUMP GP
1243027	PUMP GP	1620770	PUMP GP-PS	2243238	PUMP GP-WT
1246662	PUMP GP-GR	1628869	PUMP GP	2258016	PUMP GP-WT
1247800	PUMP G.	1630059	PUMP GP.	2258329	PUMP AS



PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION
2261191	PUMP GP	2S0154	OIL PUMP	3S4386	OIL PUMP
2274300	PUMP AS.WATER	2S7209	WATER PUMP	3T0300	PUMP G.
2274301	PUMP AS.WATER	2S7873	OIL PUMP	3T0301	PUMP G. GEAR
2289129	PUMP GP	2S9535	E.OIL PUMP	3T1445	PUMP G. GEAR
2321835	PISTON PUMP	2V6124	PUMP G. GEAR	3T1446	PUMP G. GEAR
2335220	PUMP GP	2W1223	PUMP G.	3T4604	PUMP G.
2346110	PUMP GP-WT	2W1225	WATER PUMP	3T5446	PUMP G.
2364420	PUMP AS-WT	2W1227	WATER PUMP	3T7897	PUMP G. GEAR
2396142	PUMP GP	2Y6399	PUMP G.	3T8098	PUMP G.
2442228	PUMP	3G1686	PUMP G.	3T8359	PUMP G. GEAR
2681900	PUMP G	3G2640	PUMP G. GEAR	4M1001	OIL PUMP
2915304	PUMP GP-WT	3G2848	PUMP G.	4N0733	PUMP G.
3318905	PUMP AS.	3G2858	PUMP G. GEAR	4N0735	PUMP G.
3502508	PUMP	3G4661	PUMP G.GEAR	4N1101	PUMP G.-FUEL
3502536	PUMP W.	3G4768	PUMP G. GEAR	4N4864	FUEL PUMP
3502537	PUMP GP-WA	3G5810	PUMP G. VANE	4N4873	FUEL PUMP
3520205	PUMP AS-WATER	3G5863	PUMP G.	4N4878	FUEL PUMP
3520206	PUMP	3G5868	PUMP G. GEAR	4N4880	FUEL PUMP
3522080	PUMP GP	3G6856	PUMP G. GEAR	4N5837	PUMP G.
3522109	PUMP GP-WA	3G6916	SECTION PUMP	4N8734	PUMP G.
3522123	PUMP GP-WA	3G7634	PUMP G	4N8735	PUMP G.
3522125	PUMP GP. WATER	3G7635	PUMP G	4P3683	W.PUMP G.
3522138	PUMP AS-WA	3G7636	PUMP G	4P4186	PUMP
3522139	PUMP GP-WA	3G7637	PUMP G.	4S8660	OIL PUMP
3522152	WATER PUMP	3G7639	PUMP G	4T0508	VANE PUMP
1P0005	FUEL PUMP	3G7641	PUMP G.	4T0509	HYDRAULIC PUMP G.
1P2187	PUMP G. GEAR	3G9891	PUMP G. GEAR	4T2506	PUMP G.PISTON
1P4220	PUMP G.	3N2078	FUEL PUMP	4T2767	PUMP G.-PISTON
1P4231	OIL PUMP	3P0203	PUMP G.	4W5477	PUMP G.FUEL
1P6752	PUMP G.	3P0204	PUMP G.	4W5479	PUMP G.
1T1810	PUMP G.	3P0380	PUMP G. GEAR	4W5481	PUMP G.TRSSFR
1U1625	PUMP G. GEAR	3P0891	PUMP G.	4W7589	PUMP G.
1U1779	PUMP G. GEAR	3P0892	PUMP G. GEAR	5H1719	OIL PUMP
1U3840	PUMP G.	3P1672	PUMP G.	5I4407	PUMP GP
1U3920	PUMP G	3P4002	OIL PUMP	5J7815	VANE PUMP
1W0568	F.TR.PUMP	3P4855	OIL PUMP	5M1670	OIL PUMP
1W1695	PUMP G-FUEL TRAN-	3P6293	PUMP G	5M6488	PUMP G.
1W1700	PUMP G.FUEL TRAN-	3P6814	OIL PUMP	5M7864	OIL PUMP
2P1784	PUMP GROUP	3P6816	OIL PUMP	5S1601	OIL PUMP G.
2P3645	PUMP G. GEAR	3P7623	PUMP G. GEAR	5S4359	OIL PUMP
2P3952	PUMP OIL	3P7958	PUMP G.	5S6684	WATER PUMP G.
2P6876	PUMP G.	3P9240	PUMP G. GEAR	5S7863	OIL PUMP
2P7830	OIL PUMP	3S2616	OIL PUMP	6C0570	PUMP G

PUMP RANGE



OUR PRODUCTION

INDUSTRIAL SPARE PARTS

PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION
6D8202	PUMP A.GEAR	6P7358	PUMP G. GEAR	7S8595	PUMP G.
6E0838	PUMP G.	6P7361	PUMP G. GEAR	7S8660	OIL PUMP A.
6E1279	PUMP G.	6R1954	PUMP GP	7T2731	PUMP G.
6E2046	PUMP G. GEAR	6T0016	PUMP G. GEAR	7T2732	PUMP G.-GEAR
6E2927	VANE PUMP	6T0017	PUMP G. GEAR	7T4764	PUMP G. GEAR
6E2928	PUMP G.VANE	6T3651	PUMP G.	7T4778	PUMP G. GEAR
6E2930	VANE PUMP	6T3935	PUMP G.	7T4779	PUMP G. GEAR
6E2931	VANE PUMP	6T3936	PUMP G. GEAR	7W4457	PUMP
6E2932	PUMP G	6T4257	PUMP G. GEAR	8E1217	PUMP G.
6E3136	PUMP G	6T4258	PUMP G. GEAR	8E6709	PUMP G.
6E3137	PUMP G	6T9651	PUMP G.	8E7538	PUMP G.
6E3139	PUMP G	6Y1259	PUMP G.	8E9970	PUMP G.
6E3524	PUMP G.	6Y1260	PUMP G.	8J0498	PUMP G.
6E4182	PUMP G.	6Y3585	PUMP G.	8J5846	PUMP G.
6E4772	PUMP G	6Y3586	PUMP G.	8J6155	PUMP G.
6E5052	PUMP GP	6Y3864	PUMP G.	8J6730	PUMP G.
6E5072	PUMP GP	6Y4614	PUMP G.	8J8813	PUMP GR. GEAR
6E5539	PUMP G	6Y6712	PUMP G.	9D8655	PUMP G.
6E6012	PUMP GP	6Y8764	PUMP GP	9D8665	PUMP G.
6E6406	PUMP G.	6Y8765	PUMP GP	9G3055	PUMP G. GEAR
6E6659	PUMP G.	7C1531	PUMP G.	9J0455	PUMP G. GEAR
6E6666	HYD.PUMP	7C1772	PUMP G.	9J0484	PUMP G.
6I0253	PUMP A.	7C4508	PUMP G.	9J0809	PUMP G.
6I0912	PUMP A.	7C6438	PUMP G.	9J1295	PUMP G.
6I1343	PUMP G.	7E7398	WATER PUMP	9J5047	PUMP G
6I1346	OIL PUMP	7E9195	WATER PUMP	9J5048	HD.PUMP
6I3890	WATER PUMP GP	7G2262	PUMP G. GEAR	9J5049	PUMP G.
6N1030	E.OIL PUMP	7G3200	PUMP G. GEAR	9J5050	HYDRAULIC PUMP
6N1813	FUEL PUMP	7G3815	PUMP G. GEAR	9J5053	PUMP G.VANE
6N2450	ENGINE OIL PUMP	7G4856	PUMP G.	9J5055	HYD.PUMP
6N2460	PUMP G.-OIL	7G5301	PUMP G.	9J5056	PUMP G.
6N2642	OIL PUMP	7J0582	PUMP G.	9J5058	HYD.PUMP
6N2790	PUMP G.	7J0584	PUMP G.	9J5059	VANE PUMP
6N2792	OIL PUMP	7J0590	HYD. PUMP	9J5064	PUMP G.
6N2793	PUMP G.	7J2194	HYD.PUMP	9J5070	HYD.PUMP
6N2809	OIL PUMP	7J4882	PUMP A.	9J5075	PUMP G.
6N2815	OIL PUMP ENG.	7J8199	PUMP G.	9J5080	PUMP G.
6N2820	ENG.OIL PUMP	7N4170	ENG. OIL PUMP	9J5082	PUMP G.
6N2821	ENG.OIL PUMP	7S4577	OIL PUMP	9J5763	PUMP G.
6N6015	WATER PUMP	7S4629	OIL PUMP	9J5764	PUMP G. GEAR
6N6424	WATER PUMP	7S6875	OIL PUMP A.	9J8184	PUMP A. HYD.
6P0824	PUMP G.GEAR	7S7400	OIL PUMP A.	9J8190	HYD.PUMP
6P4996	PUMP G.	7S7602	OIL PUMP	9J8201	HYD. PUMP



PART. NUMBER	DESCRIPTION
--------------	-------------

9J8277	PUMP G.
9J8769	PUMP G
9M4953	FUEL PUMP
9M4955	FUEL PUMP
9M8284	OIL PUMP
9P2653	PUMP G.
9P9610	PUMP G. GEAR
9S1195	E.OIL PUMP
9S6590	OIL PUMP
9S6788	OIL PUMP
9T1080	PUMP G.
9T1417	PUMP G.
9T3680	PUMP G
9T3714	PUMP G.
9T3866	PUMP G
9T4327	PUMP GRP
9T5715	PUMP G.
9T6577	HYD.OIL PUMP
9T6813	PUMP G.
9T6857	PUMP
9T7099	PUMP G
9T7414	PUMP G.
9T7465	PUMP G
9T7468	PUMP G.
9T8346	PUMP G
9T8647	PUMP G.
9T9909	PUMP G.
9T9912	PUMP GP
9U9087	PUMP G.
9W1723	PUMP G. GEAR

KOMATSU®

PART. NUMBER	DESCRIPTION
--------------	-------------

743072203	PUMP A.
743672202	PUMP A.
744167503	PUMP A.
744466100	PUMP
744466103	PUMP A.
1441311111	PUMP A.
1541341123	PUMP
1751321124	PUMP
1751323500	PUMP
1951311124	PUMP
6124611004	WATER PUMP A.
6128521014	OIL PUMP
6136521100	PUMP G.
6136611102	WATER PUMP
6150511004	OIL PUMP
6150611101	WATER PUMP
6151511005	OIL PUMP
6151611121	WATER PUMP A.
6151621100	WATER PUMP A.
6209611100	WATER PUMP
6211511000	OIL PUMP
6211621403	WATER PUMP
6212611205	WATER PUMP
6222631200	WATER PUMP
6676631015	WATER PUMP
7041138100	PUMP A.
7051134011	PUMP A.
7051135010	PUMP G.
7051136100	PUMP A.
7051138010	PUMP A.
7051140010	PUMP A.
7051236010	PUMP A.
7051238211	PUMP A.
7052132050	PUMP
7052132051	PUMP A.
7052240070	PUMP A.
7052240100	PUMP A.
7053031203	OIL PUMP
7054101050	PUMP A.
7054101320	PUMP A.

PART. NUMBER	DESCRIPTION
--------------	-------------

7055120170	PUMP G.
7055120370	PUMP A.
7055122000	PUMP A.
7055130190	PUMP
7055130290	PUMP HYDRAULIC
7055220240	PUMP
7055230080	PUMP
7055230280	PUMP A.
7055634240	PUMP A.
0740040500	OIL PUMP
0742971203	PUMP
0743271203	PUMP A.
0743272103	PUMP
0743371103	PUMP
0743872202	PUMP
0744072202	PUMP
0744271102	PUMP
0744367504	OIL PUMP
0744666200	PUMP A
14X4911600	PUMP

PUMP RANGE

AFTER-MARKET



INDUSTRIAL SPARE PARTS

CATERPILLAR®

PART. NUMBER	DESCRIPTION
358006	PUMP A.
382019	PUMP US
539098	PUMP
676319	PUMP A.
685167	PUMP
697339	PUMP
767914	PUMP
854923	PUMP GEAR
874750	PUMP GR. MAIN
912207	PUMP
929124	PUMP
1004952	WATER PUMP ASSY
1025844	W.PUMP
1032984	PUMP
1052155	PUMP G
1057322	PUMP G
1072473	PUMP G.
1077732	PUMP GP-F
1093420	PUMP G
1094197	PISTON PUMP
1107549	PUMP G
1108478	PUMP GP
1116841	PUMP GP
1118399	PUMP GP
1127358	GEAR PUMP
1140604	PUMP G
1140631	PUMP G.
1159899	PUMP GP
1159901	PUMP GP.GEAR
1164624	PUMP G.
1169526	PUMP GP
1175033	PUMP A-WAT
1177760	PUMP G
1179611	PUMP GP
1181143	PUMP GP P
1194042	PUMP
1206746	PUMP GP
1213409	PUMP GP
1214019	PUMP G

PART. NUMBER	DESCRIPTION
1218917	PUMP GP-GR
1236765	PUMP GP
1238509	PUMP GP
1243718	PUMP GP
1246702	PUMP GP
1265916	WATER PUMP
1287228	PUMP GP
1323630	PUMP GP
1336911	PUMP GP
1336912	PUMP GP
1363965	PUMP GP
1368898	PUMP GP
1376842	PUMP-GP-VN
1380529	PUMP
1400295	PUMP GP
1411503	PUMP G
1418208	PUMP GP
1435608	WATER PUMP GP.
1438498	PUMP-FUEL
1450771	PISTON PUMP
1451077	PUMP G
1453996	PUMP GP
1453997	TRIPLE GEAR PUMP
1455291	PUMP G
1459047	PUMP GP
1463685	PUMP
1471476	PUMP G
1492685	PUMP GP-PR
1507585	PUMP GP
1518277	PUMP GP-GR
1522914	PISTON PUMP
1527767	PISTON PUMP
1527768	PUMP GP-PS
1530488	PUMP
1559248	PUMP GP-PS
1569084	PUMP GP-PS
1570956	PUMP GP
1572630	PUMP GP-GR
1575909	PUMP GP-IM

PART. NUMBER	DESCRIPTION
1576081	PUMP GP-PS
1593138	WATER PUMP ASSY
1608175	PUMP
1614112	PUMP GP.
1629207	PUMP GP-VN
1632428	PUMP
1656767	PUMP GP.
1657634	PUMP
1689027	PUMP
1694882	PUMP
1694883	PUMP
1698563	PUMP GP-GR
1712950	PUMP GP-PS
1725637	PISTON PUMP
1725638	D. PISTON PUMP
1729322	PUMP GP-PS
1748147	PUMP GP-VN
1756253	PUMP GP
1785195	PUMP GP-PS
1838205	PUMP GROUP WATER
1838232	PUMP
1838403	PUMP GP-GR
1843124	PUMP
1850220	PUMP G
1862821	PUMP
1877419	PUMP GP-GE
1878983	PUMP WATER
1878986	PUMP WATER
1908977	PUMP GP-F
1914612	PUMP
1946800	PUMP
1959097	PUMP GP-PS
1962238	PUMP GP-GR
1963807	PUMP
1966098	PUMP GP-PS
1968895	PUMP GP.
2021335	PUMP GP-PS
2042578	PUMP
2044996	PUMP



PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION
2080332	PUMP	2552453	PUMP -	1T0984	PUMP A.
2093258	PUMP	2590815	PUMP GP-PS	1U2039	VANE PUMP
2128169	PUMP G.	2615630	PUMP	1U2149	PUMP G.
2128177	PUMP GP-WA	2650330	PUMP	1U2824	VANE PUMP
2128559	PUMP GP-F	2672755	PUMP	1U3969	VANE PUMP
2141098	PUMP GP-PS	2726955	PUMP GP.	1U6303	PUMP
2160801	PUMP	2741512	METERING PUMP	1V5144	PUMP G.-GEAR
2162942	PUMP AS-WA	2775566	PUMP	1W3009	PUMP A
2170385	PUMP	2797861	PUMP GP-FU	1W9046	PUMP G
2175481	PUMP GP-FU	2835992	PUMP	2N9515	PUMP G
2191965	PUMP GP	2845565	PUMP	2P2570	PUMP G.
2205623	PUMP	2856716	PUMP	2P9313	PUMP G. GEAR
2220103	PUMP	2929964	PUMP GP	2S7920	OIL PUMP
2220104	PUMP GP-HY	2954070	PUMP AS	2W4403	PUMP G-FUEL TRANSFER
2220110	PUMP	2999267	PUMP GP F	2W8005	PUMP G.
2231608	PUMP	3110053	PUMP GP-WA	2W9726	PUMP G. WATER
2243254	PUMP AS-WA	3154678	PUMP AS	2Y3734	PUMP A.
2243255	PUMP GP-WA	3166864	PUMP GP-F	3A1692	PUMP A.
2244430	PUMP	3178021	PUMP	3D6351	PUMP G.
2244432	PUMP	3186357	PUMP	3G1239	VANE PUMP
2246369	PUMP	3217800	PUMP-FUEL	3G1240	VANE OUMP
2266034	PUMP	3264635	PUMP GP-FU	3G1752	VANE PUMP
2275476	PUMP	3295736	PUMP	3G2875	PUMP G.-GEAR
2279383	D. GEAR PUMP	3318906	PUMP GP-GE	3G4094	PUMP G
2283636	PUMP	3359117	PUMP GP-WA	3G4095	PUMP G
2290102	PUMP GP-PS	3362213	WATER PUMP	3G4097	PUMP G
2352716	PUMP	3500666	PUMP	3G4601	VANE PUMP
2354108	PUMP	3529259	PUMP GP-GR	3G4602	PUMP G.
2354109	PUMP	3541672	PUMP GP-WA	3G5867	PUMP G.
2356501	PUMP GP-GR	3544754	WATER PUMP	3G5869	PUMP G. GEAR
2367296	PUMP	3712710	PUMP G	3G5958	PUMP G. GEAR
2369105	PUMP	3738014	PUMP-OIL	3G6846	PUMP G-VANE
2373960	PUMP GP-GE	3801715	PUMP WATER	3G7412	VANE PUMP
2387642	PUMP	3848611	PUMP FUEL TRANSFER	3G7428	PUMP G
2402647	PUMP	3917998	PUMP FEED	3G7429	PUMP G.
2418686	PUMP	4160021	PUMP AS	3G7638	PUMP G
2419157	PUMP	4211808	PUMP	3G7640	PUMP G.
2419299	PUMP	4228160	PUMP GP-VN	3G9801	PUMP G.
2448483	PUMP GP	4264806	PUMP GP-F	3N4851	PUMP G.
2464486	PUMP	4304553	PUMP	3P8211	PUMP G.
2506878	WATER PUMP	19241501	PUMP	3T4357	PUMP G.
2533459	WATER PUMP	1P1991	OIL PUMP	3T5447	PUMP G.
2545147	PUMP	1S3197	PUMP G.SCAVENGE	3T7465	PUMP

PUMP RANGE



AFTER-MARKET

INDUSTRIAL SPARE PARTS

PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION
4C3147	PUMP	6J6600	PUMP A	8M9559	OIL PUMP
4C7195	PUMP	6N2801	PUMP G.	8N1630	PUMP G.FUEL
4D4661	PUMP A	6N5723	PUMP G.	8N1929	PUMP G
4I1023	PUMP G	6T6147	PUMP G. GEAR	8N4997	PUMP A FUEL
4K3878	PUMP A,-	6T8217	PUMP G. GEAR	8N4997	PUMP A FUEL
4L8800	WATER PUMP	6T8218	PUMP G. GEAR	9G3056	PUMP G. GEAR
4P7168	PUMP GP	6U8013	PUMP GP	9J4983	PUMP G.
4T0382	PUMP GP	6Y0807	PUMP G.	9J5044	PUMP G. VANE
4T2606	PUMP G.	6Y6711	PUMP GP-GR	9J5051	PUMP G.VANE
4T5030	PUMP G	7C1285	PUMP G	9J5052	PUMP G
4T5614	PUMP G. GEAR	7C3134	PUMP	9J5060	PUMP G-VANE
4T5615	PUMP G. GEAR	7C3613	PUMP G	9J5061	HYD.PUMP A.
4T6827	PUMP G	7E2971	PUMP G.	9J5063	PUMP G
4T7025	PUMP G.-PISTON	7E5536	PUMP GP	9J5065	PUMP G-VANE
4T8584	PUMP G	7E7399	WATER PUMP	9J5067	PUMP G
4W3366	PUMP A.	7G1013	PUMP G.	9J5078	PUMP G.VANE
4W5868	PUMP A	7J0583	PUMP G.	9J5083	PUMP G.
4W7684	PUMP G	7J0585	PUMP G.	9J5135	VANE PUMP
5I7507	PUMP A	7J0587	PUMP A.	9J8182	HYD.PUMP
5U0557	PUMP GP	7J0611	PUMP A	9J8183	VANE PUMP
5U0558	PUMP GP	7M6621	OIL PUMP	9J8187	PUMP G
5Y0245	PUMP G	7S2983	PUMP G.	9J8192	PUMP G-VANE
5Y1309	PUMP A FUEL	7S9521	PUMP G.	9J8195	PUMP G-VANE
6E1219	PUMP G.	7T4311	PUMP G. GEAR	9J8197	PUMP A.
6E1229	PUMP G.	7T8890	PUMP A	9J8199	PUMP G.
6E1412	PUMP GRP	7T8891	PUMP A	9J8204	PUMP G.
6E2929	VANE PUMP	7U4889	PUMP AS	9M8200	PUMP G.
6E3364	PUMP G	7U6875	PUMP GP	9N0495	PUMP G.
6E4386	PUMP G	7U7307	PUMP GP	9N3288	PUMP G. WATER
6E4469	PUMP G	7U9191	PUMP GP	9N7746	PUMP
6E4730	PUMP G	7W0053	PUMP G.	9P7239	PUMP G.
6E4934	PUMP GP	7W2554	PUMP G.	9Q5328	PUMP GP-GE
6E5650	PISTON PUMP	7W4557	PUMP G.	9T0436	PUMP G.
6E5831	PUMP	7Y4002	PUMP G	9T0486	VANE PUMP
6E5965	PUMP GP	7Y4012	PUMP G	9T1416	PUMP G
6E6425	PUMP G	8E0416	PUMP GP.TRANSM.	9T1619	PUMP G. GEAR
6E6476	PUMP G	8I4458	PUMP	9T1763	VANE PUMP
6E6482	PUMP	8J2059	PUMP G	9T1802	PUMP G.
6E6483	PUMP G	8J4513	PUMP	9T2108	PUMP G.
6E6563	PUMP G	8J4515	PUMP G. GEAR	9T3870	PUMP G.
6I0571	PUMP	8J5945	PUMP G.	9T4104	PUMP G. - PISTON
6I4370	PUMP AS	8J6731	PUMP G.	9T4699	PUMP G
6I4722	PUMP GP WT	8J9417	PUMP G.	9T4833	PUMP G. PISTON



PART. NUMBER	DESCRIPTION
--------------	-------------

9T5456	PUMP G.
9T5611	PUMP G.
9T6123	VANE PUMP
9T7916	VANE PUMP
9T9839	PUMP G
9V0720	PUMP G. GEAR
9W4704	PUMP G. GEAR
9W9310	PUMP G.

CUMMINS®

PART. NUMBER	DESCRIPTION
--------------	-------------

2881688	WATER PUMP
2881804	ISBE WATER PUMP
3011389	PUMP
3034233	PUMP FUEL
3034243	PUMP,GEAR FUEL
3034245	PUMP
3047549	OIL PUMP
3051408	WATER PUMP
3073693	PUMP,WATER
3286278	WATER PUMP
3415366	PUMP,WATER
3635807	PUMP
3683652	ISX WATER PUMP
3687130	ISX WATER PUMP WITH BACK HOUSING
3800745	PUMP,WATER
3800828	PUMP
3800883	PUMP,WATER
3800984	PUMP
3801708	PUMP GP
3801784	PUMP
3801788	PUMP
3802004	WATER PUMP
3802973	PUMP
3802975	WATER PUMP
3803138	PUMP,WATER
3803369	PUMP OIL
3803402	WATER PUMP
3803403	PUMP
3803605	PUMP,WATER
3803698	PUMP,LUBRICATING OIL
3804826	PUMP WATER
3821572	PUMP
3918000	FUEL TRANSFER PUMP
3928396	PUMP
3930337	OIL PUMP
3930338	PUMP
3936320	PUMP,FUEL TRANSFER

PART. NUMBER	DESCRIPTION
--------------	-------------

3936321	PUMP,FUEL TRANSFER
3960203	OIL PUMP
3966841	WATER PUMP
3968187	FUEL PUMP
3968190	FUEL PUMP ELE
3973398	OIL PUMP
3990105	PUMP FUEL
3990106	PUMP,FUEL TRANSFER
4003950	PUMP,LUBRICATING OIL
4089647	WATER PUMP
4089909	WATER PUMP
4089910	WATER PUMP
4891252	WATER PUMP
4935005	FUEL PUMP
4937766	FUEL LIFT PUMP
4937767	FUEL PUMP
4939585	PUMP
4939586	OIL PUMP
4939587	PUMP LUBRICATING OIL
4939588	OIL PUMP
4941464	OIL PUMP
4983414	PUMP,FUEL TRANSFER
4983585	PUMP,FUEL TRANSFER
4988753	PUMP,FUEL TRANSFER
4988769	FUEL TRANSFER PUMP
5260632	PUMP,FUEL TRANSFER
AR10172	LUBE OIL PUMP
AR12338	OIL PUMP
AR9834	LUBE OIL PUMP
AR9835	LUBE OIL PUMP

PUMP RANGE

AFTER-MARKET



INDUSTRIAL SPARE PARTS

KOMATSU®

PART. NUMBER	DESCRIPTION
740030100	PUMP ASS'Y
740030101	PUMP ASS'Y
742971201	PUMP ASS'Y
743072100	PUMP
743072200	PUMP ASS'Y
743072201	PUMP ASS'Y
743072301	PUMP A.
743171100	PUMP
743172100	PUMP
743271200	PUMP ASS'Y
743271202	PUMP ASS'Y
743272100	PUMP
743272101	PUMP A. -STEERING
743272200	PUMP ASS'Y
743272201	PUMP ASS'Y
743272202	PUMP ASS'Y
743371101	PUMP HYDRAULIC
743371102	PUMP A-TRANSMISSION
743371103	PUMP
743372400	PUMP A.
743472201	PUMP ASS'Y
743472801	PUMP ASS'Y
743666100	PUMP ASS'Y
743666101	PUMP ASS'Y
743666102	PUMP ASS'Y
743666103	PUMP ASS'Y
743672200	PUMP ASS'Y
743871200	PUMP
743872200	PUMP ASS'Y
743872201	PUMP
743872902	PUMP ASS
744072902	PUMP ASS'Y
744072903	PUMP ASS'Y
744167500	PUMP ASS'Y
744167501	PUMP
744271100	PUMP ASS'Y
744271101	PUMP
744366504	PUMP ASS'Y
744371103	PUMP HYDRAULIC

PART. NUMBER	DESCRIPTION
744466101	PUMP
744466102	PUMP
744467100	PUMP ASS'Y
744467500	PUMP ASS'Y
744467501	PUMP ASS'Y
744467502	PUMP ASS'Y
744666100	PUMP
744666101	PUMP
744866100	PUMP ASS'Y
744866101	PUMP
744866105	PUMP ASS'Y
744866108	HYDR.PUMP
744866802	PUMP ASS'Y
744866803	PUMP ASS'Y
1381313530	PUMP CONVERTER
1441311110	PUMP
1441311122	PUMP
1541341120	PUMP
1951311122	PUMP
1954934100	PUMP ASS
1984934100	PUMP
6124611000	WATER PUMP
6124611001	PUMP
6127511002	OIL PUMP A
6127511003	OIL PUMP A
6127611003	WATER PUMP ASS'
6127611006	WATER PUMP
6127611008	WATER PUMP
6128511001	OIL PUMP A
6128511002	OIL PUMP A
6128511003	OIL PUMP A
6128511004	OIL PUMP A
6128511005	OIL PUMP A
6128511006	OIL PUMP A
6128511007	OIL PUMP A
6128521000	OIL PUMP A
6128521001	OIL PUMP A
6128521002	OIL PUMP
6128521003	OIL PUMP A

PART. NUMBER	DESCRIPTION
6128521004	OIL PUMP A
6128521010	PUMP
6128521011	PUMP
6128521012	PUMP
6136511000	PUMP ENGINE OIL
6136511001	PUMP ENGINE OIL
6136611100	WATER PUMP ASS'
6136611500	WATER PUMP ASS'
6138611570	WATER PUMP
6138611860	WATER PUMP
6150611104	WATER PUMP
6150611105	WATER PUMP
6162531010	OIL PUMP ASS'Y
6162631010	WATER PUMP ASS'
6162631011	WATER PUMP ASS'
6162631013	WATER PUMP ASS'
6162631016	WATER PUMP ASS'
6204611101	WATER PUMP ASS'
6204611103	WATER PUMP ASS'
6204611104	WATER PUMP ASS'
6204611304	WATER PUMP
6204611602	WATER PUMP ASS'
6205611204	WATER PUMP
6206611101	WATER PUMP
6206611103	WATER PUMP
6206611500	WATER PUMP ASS'
6206611502	WATER PUMP
6206611503	WATER PUMP
6206611504	WATER PUMP ASS'
6206611505	WATER PUMP ASS'
6206611701	WATER PUMP
6209511700	OIL PUMP
6211511002	OIL PUMP ASS'Y
6211611100	PUMP
6211611101	PUMP
6211611400	WATER PUMP
6211611402	WATER PUMP
6212611201	PUMP WATER
6212611203	PUMP WATER



PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION
6212611300	WATER PUMP	7051133100	PUMP	7055534160	PUMP
6212611301	WATER PUMP	7051134010	PUMP ASS'Y	7055634100	PUMP ASS'Y
6212611302	WATER PUMP	7051134060	PUMP ASS'Y	7055634180	PUMP ASS'Y
6212611303	WATER PUMP	7051134100	PUMP A.	7055644010	PUMP
6212611304	WATER PUMP	7051136000	PUMP ASS'Y	7055844050	PUMP ASS
6212611305	WATER PUMP	7051232110	PUMP ASS'Y	7055846000	TRANS PUMP
6221511100	OIL PUMP	7051233110	PUMP ASS'Y	7055846001	PUMP AS
6221531101	OIL PUMP ASS'Y	7051234060	PUMP ASS'Y	7055846030	TRANS PUMP
6221531110	OIL PUMP ASS'Y	7051234240	PUMP ASS	7112831120	PUMP
6221611100	WATER PUMP ASS'	7051237010	PUMP G.	7114731120	PUMP
6221611101	WATER PUMP ASS'	7051238010	HYDR.PUMP	7114741120	PUMP
6221611102	WATER PUMP ASS'	7051240830	PUMP ASS'Y	7114911120	PUMP
6261611101	PUMP	7051240831	PUMP ASS'Y	7114941120	PUMP
6261611201	WATER PUMP	7051240840	PUMP ASS'Y	7115011120	PUMP
6610511020	OIL PUMP	7051244010	PUMP ASS	7115041120	PUMP
6610511021	OIL PUMP	7051244040	PUMP	7115511120	PUMP
6610511030	OIL PUMP	7055120070	PUMP G.	38510192051	PUMP ASS'Y
6620511000	PUMP	7055120090	PUMP ASS'Y	07400-30102	PUMP ASS'Y
6620511381	OIL PUMP	7055120150	PUMP G.	07400-30200	PUMP
6620712641	PT PUMP	7055120180	PUMP ASS'Y	07400-40400	PUMP
6676631014	PUMP WATER	7055120290	PUMP ASS'Y	07400-40500	HYD. PUMP ASS'Y
6682531000	OIL PUMP	7055120400	PUMP ASS	07429-71203	PUMP ASS'Y
6710511000	OIL PUMP A	7055132080	PUMP AS	07429-72101	PUMP G.
6711611101	WATER PUMP ASS'	7055142010	PUMP ASS'Y	07429-72302	HYDRAULIC PUMP
6711621100	PUMP WATER	7055220090	HYDRAULIC PUMP	07430-66100	PUMP ASS
6731621120	WATER PUMP	7055220160	PUMP ASS'Y	07430-66101	PUMP
6732511111	OIL PUMP ASS'Y	7055230050	PUMP ASS'Y	07430-67100	GEAR PUMP
6734711720	FUEL TRANSFER PUMP	7055230250	PUMP ASS'Y	07430-67101	PUMP
6736716550	PUMP,FUEL TRANSFER	7055230350	PUMP ASS'Y	07430-72301	HYDRAULIC PUMP
6741511110	OIL PUMP	7055230360	PUMP ASS'Y	07431-11100	PUMP
6742012190	PUMP FEED	7055230390	PUMP ASS'Y	07432-71203	PUMP
6742012590	OIL PUMP	7055230490	PUMP	07432-72103	PUMP A. -STEERING
6742015040	WATER PUMP	7055230550	PUMP ASS'Y	07433-72400	PUMP A.
6742015201	OIL PUMP	7055230560	PUMP ASS'Y	07434-72902	PUMP ASS'Y
6742015525	OIL PUMP	7055230920	PUMP ASS'Y	07437-71300	PUMP
6810611100	PUMP GP-WT	7055232000	PUMP ASS'Y	07438-72202	TRANS PUMP
7042330601	PUMP ASS	7055240000	PUMP ASS'Y	07440-72202	PUMP
7042424420	PUMP ASS'Y	7055240001	PUMP ASS'Y	07441-67501	PUMP
7042428201	PUMP ASS'Y	7055240160	PUMP ASS'Y	07442-71102	PUMP
7042428202	PUMP ASS'Y	7055242090	PUMP ASS'Y	0744271102E	PUMP
7042828050	PUMP	7055342010	PUMP AS	07442-71802	PUMP ASS'Y
7043032110	PUMP ASS'Y	7055534110	PUMP ASS'Y	07442-72202	PUMP ASS'Y
7043034110	PUMP ASS'Y	7055534140	PUMP ASS'Y	07443-67504	PUMP ASS'Y

PUMP RANGE

AFTER-MARKET



INDUSTRIAL SPARE PARTS

PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION	PART. NUMBER	DESCRIPTION
07443-7504	PUMP ASS.	6128-52-1005	OIL PUMP A	6240-61-1102	WATER PUMP ASS'
07444-67501	PUMP ASS'Y	6128-52-1014	OIL PUMP	6261-61-1201	WATER PUMP
07444-67504	PUMP	6130-62-1110	WATER PUMP	6620-51-1020	OIL PUMP ASS'Y
07446-66200	HYDRAULIC PUMP	6132-61-1616	WATER PUMP	6620-71-2073	PUMP
07448-66107	PUMP	6134-61-1410	PUMP	6620-71-2640	PUMP
07448-66500	PUMP ASS'Y	6135-61-1500	WATER PUMP	6676-62-1013	PUMP
110MC01014	PUMP	6136-51-1002	PUMP G.	6676-63-1015	WATER PUMP
113-15-00470	PUMP	6136-61-1101	PUMP	6678-61-1050	PUMP
113-15-34800	PUMP ASS'Y	6136-61-1401	WATER PUMP ASS'Y	6679-60-1002	PUMP
1242039H91	OIL PUMP	6136-61-1601	PUMP	6710-51-1001	OIL PUMP ASS'Y
1294831H1	OIL PUMP	6136-62-1100	PUMP	6712-62-1100	PUMP
1295885H91	OIL PUMP	6136-62-1102	WATER PUMP	6731-51-1110	OIL PUMP
144-13-11111	PUMP	6138-61-1401	PUMP	6731-62-1100E	WATER PUMP
144-13-11120	PUMP	6140-60-1110	WATER PUMP	6735-51-1111	OIL PUMP ASS'Y
145-13-31122	PUMP	6144-61-1102	PUMP	6735-71-1720	FUEL TRANSFER PUMP
145-49-00010	PUMP ASS'Y	6144-61-1301	WATER PUMP	6736-61-1402	WATER PUMP ASS'Y
14X-49-11600	PUMP	6144-61-1302	WATER PUMP	6742-01-3670	WATER PUMP ASS'Y
14Y-62-10000	GEAR PUMP	6150-51-1004	OIL PUMP	6742-01-5040E	WATER PUMP
14Y-72-15000	GEAR PUMP	6150-61-1103	PUMP	6754-61-1100	PUMP
14Y-74-23000	GEAR PUMP	6151-61-1121	WATER PUMP A.	6754-61-1530	WATER PUMP ASS'
14Y-74-26000	GEAR PUMP	6162-63-1012	WATER PUMP	6754-71-1010	INJECTION PUMP
154-13-41124	PUMP	6162-63-1014	WATER PUMP	6754-71-1012	INJECTION PUMP
175-13-11120	PUMP	6202-63-1201	WATER PUMP	704-12-38100	PUMP
175-13-21115	PUMP	6204-51-1100	OIL PUMP	704-24-26430	PUMP ASS
175-13-21123	PUMP	6204-53-1100	OIL PUMP	704-24-28200	GEAR PUMP
175-13-23500	PUMP CONVERTER	6204-61-1100	WATER PUMP ASS'Y	704-24-28230	PUMP ASS
176-76-66200	PUMP	6204-61-1601	WATER PUMP ASS'	704-71-44002	PUMP
17A-49-11100	PUMP ASS'Y	6206-51-1200	PUMP	705-11-30530	PUMP
19327-42100	WATER PUMP	6206-61-1104	WATER PUMP	705-11-32210	PUMP ASS'Y
195-13-11124	PUMP	6209-51-1100	LUBE OIL PUMP	705-11-32340	PUMP
195-13-11125	PUMP	6209-51-1201	PUMP	705-11-32530	PUMP
195-13-11126	PUMP	6209-61-1100	WATER PUMP	705-11-32540	PUMP
23A6011100	PUMP ASS'Y	6211-51-1000	OIL PUMP	705-11-33011	PUMP
23A6011102	PUMP ASS'Y	6211-61-1401	WATER PUMP	705-11-34011	HYDRAULIC PUMP
23A-60-11200	GEAR PUMP	6211-61-1403	WATER PUMP	705-11-34110	PUMP
23B6011100	HYDRALIC PUMP	6211-62-1400	WATER PUMP	705-11-34210	PUMP
23B-62-11100	PUMP	6211-62-1401	WATER PUMP	705-11-34240	PUMP
24G-74-09000	GEAR PUMP	6211-62-1402	WATER PUMP	705-11-35010	PUMP AS
385-10079282	PUMP ASS'Y	6212-51-1002	PUMP	705-11-36010	PUMP
385-10234561	PUMP	6212-62-1400	WATER PUMP ASS'Y	705-11-36100	PUMP A.
6110-63-1110	WATER PUMP	6212-62-2100	PUMP	705-11-36110	PUMP
6114-61-1100	PUMP	6222-61-1500	WATER PUMP	705-11-37240	PUMP
6124-61-1004	WATER PUMP A.	6222-63-1200	WATER PUMP	705-11-38000	PUMP ASS Y



PART. NUMBER	DESCRIPTION
705-11-38040	PUMP
705-11-40010	PUMP A.
705-11-40100	PUMP ASS'Y
705-12-28010	PUMP
705-12-32010	PUMP
705-12-34010	PUMP ASS'Y
705-12-34210	PUMP
705-12-35240	PUMP
705-12-35340	PUMP
705-12-35530	PUMP
705-12-36010	HYDRAULIC PUMP
705-12-36011	PUMP
705-12-36330	PUMP
705-12-36340	PUMP
705-12-37240	PUMP
705-12-38000	GEAR PUMP
705-12-38210	PUMP ASS
705-12-40011	PUMP ASS'Y
705-12-43030	PUMP
705-13-20540	PUMP
705-13-23530	PUMP
705-13-26530	PUMP ASS'Y
705-13-30340	PUMP
705-13-34340	PUMP
705-14-24530	PUMP
705-14-26530	PUMP
705-14-26540	PUMP
705-14-33540	PUMP
705-14-34530	PUMP
705-14-34531	PUMP
705-14-41040	PUMP ASS'Y
705-21-26060	PUMP
705-21-31020	PUMP
705-21-32051	PUMP A.
705-21-33060	PUMP
705-21-34100	PUMP
705-21-39070	HYDRAULIC PUMP
705-21-40020	PUMP
705-22-40070	PUMP A.
705-22-40090	PUMP
705-22-40100	PUMP A.
705-30-31203	PUMP AS
705-33-26540	PUMP

PART. NUMBER	DESCRIPTION
705-33-28540	PUMP
705-33-30340	PUMP
705-33-31340	PUMP
705-34-22540	PUMP
705-34-28540	PUMP ASS'Y
705-34-29540	PUMP
705-34-31340	PUMP
705-34-34340	PUMP
705-34-38240	PUMP
705-36-29540	PUMP
705-41-01050	PUMP A.
705-41-01320	PUMP A.
705-41-08010	PUMP ASS'Y
705-41-08090	PUMP
705-51-10010	GEAR PUMP
705-51-10020	PUMP
705-51-20240	PUMP
705-51-20300	PUMP
705-51-20340	GEAR PUMP
705-51-20440	PUMP
705-51-20480	PUMP
705-51-20500	GEAR PUMP
705-51-20600	GEAR PUMP
705-51-20830	PUMP
705-51-22050	GEAR PUMP
705-51-22080	GEAR PUMP
705-51-30100	GEAR PUMP
705-51-30340	GEAR PUMP
705-51-30580	GEAR PUMP
705-51-32000	PUMP ASS'Y
705-51-32050	GEAR PUMP
705-51-32250	GEAR PUMP
705-52-10050	PUMP
705-52-20050	GEAR PUMP
705-52-20090	PUMP
705-52-20100	HYDRAULIC PUMP
705-52-20240	PUMP
705-52-21070	PUMP ASS'Y
705-52-22000	PUMP ASS'Y
705-52-22100	HYDRAULIC PUMP
705-52-30040	PUMP ASS'Y
705-52-30051	PUMP ASS'Y
705-52-30052	PUMP ASS'Y

PART. NUMBER	DESCRIPTION
705-52-30130	HYDRAULIC PUMP
705-52-30220	HYDRAULIC PUMP
705-52-30270	GEAR PUMP
705-52-30280	PUMP A.
705-52-31010	PUMP ASS'Y
705-52-31080	HYDRAULIC PUMP
705-52-40130	PUMP ASS'Y
705-52-40850	GEAR PUMP
705-52-42100	PUMP ASS'Y
705-52-42170	PUMP AS
705-53-42000	HYDRAULIC PUMP
705-55-24130	PUMP ASS'Y
705-55-34180	PUMP
705-56-24030	GEAR PUMP
705-56-24080	PUMP
705-56-34240	PUMP A.
705-56-36050	PUMP ASS.
705-56-43010	PUMP
705-56-44000	HYDRAULIC PUMP
705-58-34010	GEAR PUMP
705-58-44050	PUMP ASS'Y
705-58-47000	PUMP
707-24-24420	PUMP
711-14-11120	PUMP
711-47-51120	PUMP
711-49-51121	PUMP
711-50-51120	PUMP
711-52-11120	PUMP
B07-15-11000	GEAR PUMP
DK105210-4560	FEED PUMP ASSY
DK105220-5280	PUMP ASSY

CONTACT US:

668 Dairy Flat Highway, Albany
Auckland, 0792, New Zealand
+64 9 414 5514 - 0800 60 80 20
www.earthquip.co.nz - parts@earthquip.co.nz