



Dramatic Play Area

Preschool



Product name	SKU	Width	Height	Depth	Quantity
Woodcrest Chair - 12" Seat	077-J712	1' 2"	1' 10"	1' 3"	2
Corner Shelf 24" H	077-F673	1' 2"	2' 0"	1' 2"	1
Round Woodcrest Table - 27" W x 20" H	077-C231	2' 3"	1' 8"	2' 3"	1
Woodcrest Stove	077-C361	1' 10"	2' 1"	1' 3"	1
Woodcrest Refrigerator	077-C363	1' 10"	3' 3"	1' 3"	1
Woodcrest Sink	077-C362	1' 10"	2' 1"	1' 3"	1
Woodcrest Cupboard	077-C364	1' 10"	3' 3"	1' 3"	1
Puppet Theater	077-F791	3' 6"	4' 0"	1' 6"	1
Child-Sized Rocking Chair	077-J800	1' 2"	1' 11"	1' 8"	1
Dress-up Unit	077-C705	3' 6"	3' 5"	1' 5"	1
Straight fillers (not shown)	077-F751	2.5"	1"	11.5"	4