

User's Manual English Movements Caliber

RONDA normtech

- 706.1
- 706.3
- 706.B

You have decided to buy a watch, which was assembled by a watchmaker using a Ronda movement. Please note that no watches are produced or distributed under the Ronda brand.

In case of repairs, guarantee claims and questions concerning the functioning of a watch, purchasers and consumers should contact their retailer or the watch manufacturer, for which the relevant information can be found in the sales or guarantee documentation provided with the watch.



Cal. 706.1

Cal. 706.3

- Pos. I** Position of rest (watch running)
- Pos. II** *During the blocking time from approx. 11.30 pm–5.30 am, no day dates can be changed using the pusher, because during this time automatic changes are in progress. Pressing the pusher during these times may damage the movement.*

Setting sequence for: day of the week, day and time (e.g. after a battery change)

1. Pull crown out to position II (watch is stopped).
2. Set the day of the week and date:
 - Turn the crown until the time of 06.00 am appears (= beyond the blocked time period).
 - Using the quick-change correction, set the date with pusher A, and the day of the week with pusher B. Then using the crown, move the hands forwards until the current date appears.

Cal. 706.1

Cal. 706.3

3. Set the time:
 - Turn the crown until the current time is displayed (remember the 24-hour cycle).
4. Push crown back into position I.

Quick-change correction for date:

Press pusher A, until the current date is displayed (remember the blocking period).

Quick-change correction for the day of the week:

Press pusher B, until the current day of the week is displayed (remember the blocking period).

Quick-change correction for the month: (cal. 706.3)

Press pusher C, until the current month is displayed (remember the blocking period).

Applies to all calibers:

Battery type: 371/SR920SW

Precision: +20/-10 seconds per month

