



RONDA normtech

– 788/708

You have decided to buy a watch, which was assembled by a watchmaker using a Ronda movement. Please note that no watches are produced or distributed under the Ronda brand.

In case of repairs, guarantee claims and questions concerning the functioning of a watch, purchasers and consumers should contact their retailer or the watch manufacturer, for which the relevant information can be found in the sales or guarantee documentation provided with the watch.

Cal. 788 / 708

- Pos. I Position of rest** (watch running)
- Pos. II Quick-change correction for date**
Blocking time for the quick-change day correction is from approx. 9.30 pm and midnight.
- Pull the crown out to position II (watch still running).
 - Turn the crown until the current date appears.
 - Push the crown back into position I.
- Pos. III Setting the time**
- Pull the crown out to position III (watch stopped).
 - Turn the crown, until the current time is displayed (remember the 24-hour cycle).
 - Push the crown back into position I.

Cal. 788 / 708

Setting the moonphase display

There is no quick-change correction available setting the moonphase.

- Pull the crown out to position III (watch stopped).
- Turn the hands forward by turning the crown, until the current moonphase display appears.
- Push the crown back into position II and set the current date using the quick change correction.
- Push the crown back into position I.

Full moon dates

	2016	2017	2018	2019	2020
JAN	24	12	02/31	21	10
FEB	22	11		19	09
MAR	23	12	02/31	21	09
APR	22	11	30	19	08
MAY	21	10	29	18	07
JUN	20	09	28	17	05
JUL	19	09	27	16	05
AUG	18	07	26	15	03
SEP	16	06	25	14	02
OCT	16	05	24	13	01/31
NOV	14	04	23	12	30
DEC	14	03	22	12	30

Cal. 788:

Battery type: 362/SR721SW

Cal. 708:

Battery type: 371/SR920SW

Precision: +20/-10 seconds per month