


Instruction Manual


for






DOTTI Instruction Manual









Visit our tutorial page for more video and info http://www.wittidesign.com/tutorial/dotti

Turning On/Off DOTTI

- 1) Press and hold the Power Touch Sensor for 3s to turn on/off DOTTI.
- 2) Slowly slide the touch panel left or right to switch between various modes
 - Favorite Icon
 - Animation
 - Clock (Auto sync with phone)
 - Shaking Dice Game (Shake to activate)
 - Battery Life Indicator
 - Notification/Sleep Mode (Screen is off)

Connecting and Using DOTTI

- 1) Download the DOTTI free App from App Store or Google Play. Keyword Search: Dotti
- 2) To connect to DOTTI, launch the App, click on "DOTTI". When prompt for pairing password, please enter "123456"
- 3) Please allow DOTTI to access your notification settings.
- 4) You can use DOTTI App to do the following:
 - Setup 8 favorite Icons
 - Setup favorite Animation
 - Customize Icon for Shaking Game
 - Customize Notifications
 - Play Music
 - Rename DOTTI
 - Turn DOTTI into Notification mode

Setting up and Receiving Notifications

- 1) You will need to pair DOTTI in order to receive notifications. Select Notifications from the App menu, when prompt for pairing password, please enter "123456"
- 2) If you received a notification, corresponding icon will blink. If you received more than 1 notification, all corresponding icons will cycle through.

- 3) If you read the notification on your phone, the corresponding icon on DOTTI will turn off. You can also slide the top panel on DOTTI to clear all notifications on DOTTI (Phone notifications will still exist)
- 4) You can customize which notifications to receive via the App
- 5) DOTTI will be connected to your smartphone automatically once in range to receive notifications. (Please ensure Bluetooth is turned on).
- 6) Once you have paired your phone with DOTTI, other phones cannot access this DOTTI. You will need to unpair/forget DOTTI in your phone Bluetooth settings before other phones can access it.

Renaming DOTTI

- 1) You can rename DOTTI at the App Settings to differentiate between various DOTTI.
- 2) Please note that the word "- DOTTI" will be appended to the name you specified.
- 3) Please make sure you restart DOTTI for the name change to take effect.

Charging DOTTI

- 1) Use the Micro USB cable to charge DOTTI via Micro USB port. Input 5V.
- 2) The Battery Indicator light will flash while charging, and will stay on when DOTTI is fully charged
- 3) DOTTI should take around 2 to 3 hours until fully charged
- 4) The battery indicator mode has 3 level of battery indication. Full, 50%, and below 25%.

Resetting DOTTI

If DOTTI becomes non-responsive, you can reset DOTTI by using a small pin to push the reset button located at the bottom of DOTTI.

Troubleshoot

- 1) Light does not turn on Please plug in USB cable to make sure DOTTI is charged. Press the Power button for 3 seconds to make sure the unit is turned on.
- 2) No reaction when sliding the top sensors Sometimes the touch sensor can be affected by surrounding environment. Place DOTTI on table, restart DOTTI, wait for 2s, and slowly slide the top from left to right with light pressure. Reset DOTTI if problem persists.
- 3) Cannot find DOTTI on the App Please make sure Bluetooth is turned on. Please also make sure no other phone is connected to the DOTTI. If problem persists, restart both DOTTI and the App.

- 4) App cannot control DOTTI
 Please make sure Bluetooth is turned on. The App might be disconnected to DOTTI,
 go back to device page and reselect the corresponding DOTTI. If problem persists, restart
 both DOTTI and the App.
- 5) Notifications cannot be received Please make sure Bluetooth is on. If only one specific Notification cannot be received, please switch off and switch on that Notification again. If all Notifications cannot be received, please make sure you have allowed DOTTI to access your Notifications Access in your phone settings. If problem persists, please try to unpair and restart DOTTI, and reconnect again.
- 6) DOTTI does not reconnect automatically to receive notifications
 If you use the slide panel to switch DOTTI into notification mode, it could go into sleep mode if
 the phone is disconnected for a long time. This is for conserving battery. If you slide DOTTI to
 another other mode (ie, clock, favorite icon), DOTTI will automatically reconnect to your phone.
 You can use DOTTI App to turn DOTTI into notification mode if you want it to always automatically
 reconnect. Please note that battery standby time might not last for 1 month in this case.
- 7) DOTTI name does not change after set Please restart DOTTI and check the name again

For further Assistance, please contact us at service@wittidesign.com



DOTTI User Guide http://www.wittidesign.com/manuals/dotti/



Dotti App http://www.wittidesign.com/download/dotti/



Keyword: Dotti



FCC and CE manual

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- -Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -Consult the dealer or an experienced radio/TV technician for help

Due to the used enclosure material, the GSM mobile phone shall only be connected to a USB Interface of version 2.0 or higher. The connection to so called power USB is prohibited.

Do not use the mobile phone in the environment at too high or too low temperature, never expose the mobile phone under strong sunshine or too wet environment. The suitable temperature for the phone and accessories is 0°C-40°C.

CAUTION RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS

Regulatory Conformance

Hereby, Corporation declares that this device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

For the declaration of conformity, visit the Web site www.wittidesign.com/certification.

Notice: Observe the national local regulations in the location where the device is to be used. This device may be restricted for use in some or all member states of the European Union (EU)

