





Wood Aroma Diffuser User Manual



General Features

1. Ultrasonic atomizes water and essential oil, instead of heating or burning them which may destroy their original molecular structure.
2. Ultrasonic atomization vibrates at 2.4MHz per second, making water and essential oil molecules easily absorbed by our body.
3. Ultrasonic diffuses and produces abundant anions that are healthy for our body.
4. LED light provides soft illumination and also has the night-light function.
5. The diffuser has two selectable spraying modes.
6. It can be used as a humidifier as well.
7. It combines effects of night-light and aroma-therapy.

Part Names



Operation

1. Keep the product on a flat surface. Remove the upper lid vertically.(FIG 1)
2. Connect the AC adapter to the DC socket.(FIG 2)
3. Add water to the water tank with a measuring cup (not included). Ensure the water does not exceed 100ML. DO NOT add water during using. (DO NOT use hot water over 40°C or dirty water) Add 2 or 3 drops essential oil per 100ML water.(FIG 3)
4. Put the upper lid on after adding water and essential oil.(FIG 4)
Note:Please put the upper lid on before using.
5. The "LIGHT" button is to control the light. (FIG 5)
And the "MIST" button is to control mist and on-off. (FIG 6)

Operating mode:

(1)Continuous 3-hour timing mode:

Consistent orange light : the diffuser will turn off automatically after constantly working 3 hours even though there is some water in it. After that, press the "MIST" button again, the diffuser will continue spraying mist until water runs out.

(2)Interval mode of 30 seconds:

Breathing orange light : the diffuser will work 30 seconds, and stop 30 seconds.

(3)Off :

- No light, no mist.
- Long press the light button to turn off the light.
- Long press the mist button to turn off the diffuser. Or press it three times to turn off the mist.

Note: The diffuser will switch off automatically when water runs out.

6. When the power is on, the product is in a standby mode.
7. If there's a lack of water in the tank, even though press the function on/off button, the product will automatically turn off.
8. Mist and light switches off automatically when water runs out.




FIG.1



FIG.2




FIG.3




FIG.4




FIG.5




FIG.6

Precautions

Please check the followings to avoid product malfunctions:

- The slight different mist concentration is normal.
- Water, humidity, temperature and wind direction will affect mist.
- Only 100% natural essential oil can be used. Those containing chemicals, spices or impurities will cause product malfunctions.
- Please clean the tank as per the maintenance instructions before changing another essential oil.
- Do not reform, repair, or disassemble the machine by nontechnical personal, if any questions, please contact with our after-sale service.
- Do not stab, twist and stretch the cord. And keep the AC adapter far away from high temperature.
- Please stop using immediately when the AC adapter is damaged.
- Do not use the unit if there is an abnormal odor or sound. If it's hot to touch, a product malfunction may be caused.
- Essential oils may stain, In the event of spillage, please wipe away with a soft cloth.
- Do not let mist vent directly to furniture, clothing, walls etc.
- Keep away the unit from direct sunshine heat sources and air conditioners.
- Always keep the unit on a stable and flat surface. Do not place the unit on carpet, duvet or unstable area.
- Keep away the unit from other electronic equipments, such as TV and Auto equipment.
- Do not cover the unit to avoid ponding.
- Use tap or purified water only.
- Do not move the unit during using.
- Keep it out of reach of children. And it's also not suitable for people who are short of production realization.

Specifications

Size	(D)90 x (H)158MM
Weight	Approx 275g
Input Power/ Output Power	AC100-240V 50/60Hz DC24V 500mA
Power Cord Length	Approx 170CM
Electric Consumption	Approx 10W
Water Tank Capacity	100ML
LED Light	3pcs
Material	ABS / PP / Wood
Accessories	Power adaptor, User manual
Ultrasonic Frequency	2.4MHz