## How to Access and Play LEADERBOARD on the Spider 1000 or Spider 2000

To be able to access the Leaderboard feature, your machine must have an active internet connection. If you have not connected your machine, please look at our tutorials on how to connect your machine using either Ethernet or WiFi.

1. From the *Main Menu*, select the **Tournament Mode** option.



- 2. Choose THE LEADERBOARD
- 3. From The Leaderboard screen, you will be able to see a list of all the available Leaderboard events. You can see all the details for each event (date, game type, etc.)



- 4. Pick one of the events in which you would like to participate in.
- 5. Choose **Start Game** to go to the login screen

If you have not previously created a ranked play account, look at our tutorials on how to do so. The Leaderboard requires you have a registered account before you can participate.

- 6. From the login screen, login with your ranked play account. You can do so using one of the following 3 methods:
  - 6.1. Using the BullShooter App, scan the QR code that appears in the bottom left of your screen to login
  - 6.2. If you own a HotButton that is registered to an account, touch the button to the reader to login
  - 6.3. Tap the Bullseye on the dartboard to manually enter your accounts email address and password
- 7. Once you have successfully logged in, you should hear a sound and the name on the account should appear.
- 8. Select Start Game to start playing your games for that Leaderboard event



Note: After the completion of all games in any Leaderboard event, you will be presented with the Leaderboard standings for that particular event. You will be able to view your overall position as well as the complete list of all participants and their scores/averages.

