


BELLMAN
Since 1978



Steam Maker Operating Manual

CX-25S MANUAL

SCHEMATIC DIAGRAM




BEFORE USE



Please wash it inside
With warm soapy water
Rinse well


STEP.1

Unscrew knob
Remove head piece



STEP.3

Replace head piece
and tighten knob .




Place steamer on medium
high heat on stovetop .
Allow the machine to heat for
3-5 minutes until there is
sufficient pressure in boiler .

NEXT PAGE


Fill inside
With cold water

STEP.2



Don't over
the handle

STEP.4



Open the steam
valve for a few
seconds

to bleed water
inside the
steam tube

Open steam valve by turning
the small steam knob on the
side of machine

STEP.6

Close the steam
valve but allow a little bit of
steam continue to escape
from tube

This will prevent milk from
being sucked into the tube
when you begin to steam
the milk .

STEP.5

If the steam doesn't produce
a steady strong hiss

Raise the heat
Slightly



If steam explodes from the
tube at half turn of the knob


Reduce the heat

FROTH MILK ★★

Don't overfill !
the milk might
Triple in volume

(1) Fill a container
or pitcher with 1/3
full cold milk .

The steam tube is just
underneath the surface
of the milk



(2) Immerse
the steam tube
into the milk

(3) Slowly open the steam valve
Until you have a strong flow
of steam.

You will hear a
hissing sound
and see bubble.

(4) Move the steam tube
up as the froth builds

If you don't hear the hiss
or it turns to a dull rumble
the steam tube is too deep



NEXT PAGE

Producing rich milk foam can be a bit tricky , and may require practice .


If you end up with hot milk and little froth

try again later ~♪



Cleaning ★★

Open the steam valve
Release the pressure



STEP.1

Cold down the
machine body



STEP.2

Clean any milk
from the
steam tube




STEP.3

WARRANTY

(A) Warrants to the original purchaser of this product that the product will be free from manufacturing defects from workmanship and material for 1 year.

(B) We don't response for the damage of the product due to misusing and modification without authorized.



MANUFACTORY

: BELLMAN INTERNATIONAL INC.

OFFICAL WEBSITE

: <http://www.bellman.com.tw>

TEL : +886 6 6991606

+886 6 6991608

FAX : +886 6 6991697