



THE ESPRO PRESS P7 FOR COFFEE

Life is too short to drink anything less than excellent coffee. So if you love a great cup, this ESPRO Press will be your new best friend.

Your ESPRO Press uses our patented micro-filtration system to seal out grit so you always get a clean, rich cup of coffee. The design also stops the coffee-extraction process as soon as the filter is pushed down, so your last sip tastes just as great as your first. The double-walled, insulated stainless steel looks great and keeps your beverage hot for hours.

FRIENDS FOR LIFE, GUARANTEED.

We even guarantee it will always make a better cup.
Let's all raise a cup to that.

Espro, Inc. 169-3381 Cambie St
Vancouver BC V5Z 4R3 Canada

WWW.ESPRO.CA



esproinc



@espro

80165r0

ENGLISH

If you are not satisfied with an ESPRO® product when you receive it, or if one of our products does not perform over time, you may return it to your local representative for a repair, replacement, or refund. Damage due to improper use, lack of cleaning, or wear and tear will be repaired at a reasonable charge. This is a factory guarantee, limited only by any applicable local laws, and does not cover incidental, consequential, or special damages.

MAKING BETTER COFFEE

[1] Twist to lock both micro-filters together, and [2] screw onto the rod. [3] Add coarse-ground coffee. With an 18oz ESPRO Press P7 we typically use 4-5 tablespoons (T) coffee (18-27g) and [4] fill with hot water (202°F/94°C) to the (MIN) fill line, or 5-7T/24-36g coffee when filled to the (MAX COFFEE) line. With a 32oz ESPRO Press P7, we use 6-9T/24-36g (MIN), or 8-14T/40-70g (MAX COFFEE). [5] Stir. [6] Cover with filters and lid. Leave the plunger raised. Wait 4 minutes. [7] Press filter down slowly and pour. After each use, clean both filters inside and out. [8] Remove lid, rod, and filters. [9] Twist apart filters and unscrew rod. [10] Hand wash with a bottle brush or sponge. All parts are dishwasher safe on the top rack. Deep clean your ESPRO Press monthly: www.espro.ca/cleaning

ESPRO MODEL	COFFEE	WATER FILL LINE
18 oz P7	4-5 T/18-27 g	MIN
	5-7 T/24-36 g	MAX COFFEE
32 oz P7	6-9 T/30-45 g	MIN
	8-12 T/40-60 g	MAX COFFEE

IMPORTANT INFORMATION. PLEASE READ.

HOT: Contents are hot. Handle with care and keep away from children.

BURNS: Always use coarse-ground coffee. Never use for matcha tea or Turkish coffee. Always start with clean filters. Always stir before pressing. Don't press too fast or with more than 10 lb/5 kg of force. Pressing too hard may cause hot liquid to burn you.

SAFETY: Do not place on a stove or campfire, or in a microwave.

CLEANING: Separate and clean filters inside and out after each use. Hand wash inside and out with a bottle brush or sponge. All parts are dishwasher safe on the top rack. Deep clean your ESPRO Press monthly: www.espro.ca/cleaning

ACCESSORIES & PARTS: Paper filters (for the flavor of pour-over style coffee), extra coffee filters, and optional tea filters are all available for your ESPRO Press. Filters and seals may also wear out over time. For accessories or replacement parts, please contact your local retailer or visit www.espro.ca. Find your local retailer at www.espro.ca/retailers.

