
HARNESSES <for more info & photos click www.kGear.com/h/>

□ H152 **Camera Stabilizer Torso Strap**

The wide (40mm / 1.5") strap wraps around your torso (above your belt line) and stays in place during your shoot. It has built in elastic to provide some "give" for your breathing. The narrow strap cinches down your camera body or holster case. Some of the straps are removalbe to create a cleaner profile (see www.KGear.com/howto/ for adjustment techniques of these slider buckles).

This is the back of the strap. Adjust the overall length of strap with this slider buckle—double back to prevent slippage.

This front section sits against your torso. The large Velcro® section is used for micro-adjustments and for adding or removing the harness.



These snap-hooks are for stabilizing a holster (C-Series) case. Attach to the lower D-Rings to keep it from swaying.

The camera or case sits in this space.

The small Velcro/elastic portion is for removing the front strap as the front portion is optional when used with a holster case.

The adjustable stabilizer strap (20mm / 3/4" wide) goes around the camera lens or body. A quick-release buckle makes accessing your camera a cinch.
