

Trijicon RMR® HD Buttonology **Ouick Reference Guide**

ADMINISTRATIVE MODE

Reticle Selection

Rapid blink

Press to select reticle

To return to OPERATIONAL MODE. leave alone for 10 seconds - OR - Press A Hold for 3 seconds

Brightness Response

Press 🚹 & 🛑 Hold 3 Seconds

Rapid blink 🗢 🚹 & 🛑 Hold 3 Seconds

Slow blink ⇒ 😛 High 🛑 Low

To return to OPERATIONAL MODE. leave alone for 10 seconds - OR - Press Hold for 3 seconds

Reticle Relative Brightness

Press 🚹 & 🛑 Hold 3 seconds

Rapid blink 🗢 🚹 & 🛑

Hold 3 seconds

Slow blink 🗢 😛 & 🛑 Hold 3 seconds

Reticle blink 🔿 Reticle Brighter Dot Brighter

To return to OPERATIONAL MODE. leave alone for 10 seconds - OR - Press Hold for 3 seconds

OPERATIONAL MODE

Turn on Unit

Press 😝

Turn Off Unit

Press 🚹 & 🛑 Hold 6 seconds and release

Auto Brightness Adjustment Mode

Press 🚹 & 🛑 Hold 1 second and release

Manual Brightness Adjustment Mode

Press 😝 Press to increase brightness or to decrease brightness

Button "Lock-out" Mode

Turn off unit

Press 🔂 & 🛑 Hold 3 seconds and release

To cancel, turn unit off and then back on

Manual Brightness "Lock-in" Mode

Set Brightness

Press Hold 3 seconds and nthen release

To cancel, press 😛 & 🛑 for 1 second

Factory Default Settings

Press 🚹 & 🛑

Hold 20 seconds and then release

SYMBOL KEY

Positive Button

Negative Button

Select Either Positive or Negative Button

Center Dot Reticle Blinking

Complex Reticle Blinking



Trijicon RMR® HD Terminology



Button "Lock-out" Mode:

Allows the user to lock out the buttons in Auto Mode and Manual Mode




Manual Brightness "Lock-in" Mode:

Allows operator to lock in a specific brightness setting




Brightness Response Setting:

Choose amongst Normal Auto (default), High Auto, and Low Auto adjust settings



Reticle Selection: Select between a dot only or reticle with

center dot



Reticle Relative Brightness Setting: Adjust the contrast between dot and circle