


ANTLERS

The Antlers should be facing forward. The front of the antlers are curved, and the back of the antlers, that goes against the wall, is flat.


HEAD

Lay the head down flat against a flat surface, the head should be facing up. By the holes on the top of the head, there may be an "R" and "L" on them that will correspond with the antlers.



INSERT ANTLERS

The antlers may have an "R" and "L" on them that will correspond with the "R" and "L" in the head. Gently insert the antlers into the slots. They should go in relatively unforced. Optional After you confirm they are in properly, you may take them out and add a couple of drops of glue for permanent placement at the base of the antler.



HAPPY DANCE

You did it! Your Faux Deer Head is ready to be hung! After hanging and happy dancing, don't forget to send us a picture of your new wall!



Wall Charmers

Visit us on Social Media @WallCharmers

