

TROUBLESHOOTING

Please refer to the table below in the event of the product operating abnormally and prior to requesting repairs:

WILL NOT SWITCH ON/OFF, NO MIST OR ABNORMAL MIST

Is there enough water in the water tank?	Please add suitable amount of water in the water tank, water must never be filled over 400ml Max line.
Is the power cord connected properly?	Please disconnect, check cables and re-connect carefully.
Dirt on the atomization piece?	Please refer to maintenance instructions above to remove any dirt and keep atomization piece clean.
Cover and inner cover are not installed properly? Dirt on the air suction port on the underside of the cover?	If too much dust is in the air suction port, mist will be restricted and will not come out properly. Clean out the air suction port with provided brush or a dry cloth.

WATER LEAKAGE FROM PRODUCT

Cover and water tank are not installed properly?	Remove cover from water tank and re-install correctly. And, make sure water is not filled over 400ml Max line.
Low temperature or high humidity?	Under these conditions, the mist may condense quickly into water droplets.

SPECIFICATIONS

Dimensions	Approx. 8.75 x 7 x 7"
Weight (excluding adaptor)	Approx. 1lb
Length of Cord	Approx. 5.6ft
Electrical Rating	AC100-240V 50/60Hz DC24V 650mA
Power	Approx. 14.5W
Time Mode	1H/3H/6H/ON
Tank Capacity	400ML
LED Light	3pcs
Material	PP/ABS/PC
Accessories	AC adapter, instructional manual cleaning brush, microfiber cloth
Working Frequency	2.4MHz