

Parts Included:



USBCD1 or USBCD2 control interface.

Installation

- 1) Locate desired location to mount the control knob. Control knob can be surface or flush mounted.
- 2) Connect the WHITE wire to ground. Connect the RED wire to 12V ACC power.
- Plug the female end of the USB into the USBCD player. NOTE: Extensions can be used for extended length.
- 4) Plug the 3.5mm jack into the 3.5mm factory AUX jack.
- 5) Select the AUX source on the radio for sound.

Control Knob Function

- With the cable facing to the rear ...
- · Turn Right for track Forward
- Turn Left for track Back
- Press for Pause
- Press again for Play
- Turn and hold to the Right for Volume UP.
- Turn and hold to the Left for Volume Down.

