

## Checks before use and use on products based on diatomaceous earth.

Thank you for purchasing this product. This product is made from natural diatomaceous earth. Please check, as soon as delivery is taken, that the barbecue received is free from cracks and breaks. If this is the case, refuse it on delivery.

Do not drop the barbecue or hit it because it will crack or break, which will affect its thermal insulation,

Please handle it with care because it will be damaged even if excessive load is applied or slight impact is applied.

◆ The refractory temperature of diatomaceous earth products is approximately 800°C.

It may crack, peel, or break due to use at sudden temperature changes or high temperatures.

In addition, due to the nature of the material, cracks can occur due to thermal expansion and contraction.

However, there is no problem in using it and please replace it if the cracks have enlarged and chips have appeared.

This barbecue is very sensitive to humidity and water. Therefore, do not soak it in water and do not pour sauce over it. Also pay attention to storage. If the number of uses increases and the fireplace or partitions or top deteriorate, refrain from using it and be sure to replace it.

Please pay attention to safety and the environment around which the stove heats up during use

◆ Please remove charcoal, ash, etc. after use once the inside of the barbecue has cooled down and clean it thoroughly for the next time.

### How to use ◆

☆ Place the attached fireplace grate in the middle of the barbecue and fully open the ventilation opening and make a fire by one of the following methods:

- Put charcoal on the grill and firebox, on the gas, and put it on the stove when it catches fire.
- Place two small pieces of charcoal on the plate so as not to block the holes, put a fire starter (sold separately) on it, and light it. When the fire starter lights at the same time, press the charcoal against and surround the fire. Be careful not to burn yourself at this time.

☆ When the fire is lit, put the charcoal back according to the size of the stove, ventilate it with a fan and heat the charcoal.

Adjustment of the degree of fire is only possible when the ventilation opening is opened and closed.

Be sure to place your barbecue on a heat-resistant stand or table before use. The bottom of the barbecue is hard. If you put it on a table, it can scratch the table.

The bottom heats up during use. To avoid fires, do not place directly on tatami mats, rugs or other objects sensitive to heat or liable to catch fire (wood, plant supports, etc.), plastic, etc. or any other flammable material.

Do not touch or move the barbecue directly during use as it may cause burns or even fire.

Never leave the barbecue unattended.

☆ Sparks may fly when lifting charcoal or during combustion. Keep your face away. Keep away from children, clothing, carpets ...

☆ If you use the barbecue for a long time in a closed room, the carbon monoxide will increase and there is a risk of poisoning. Good room ventilation is necessary at all times.

After use, be sure to check that there are no more embers.

Please do not pour water on the embers inside the hearth of your Diatomaceous Earth barbecue as this will damage it.

Do not store your barbecue in a humid place.

☆ When using outdoors like on the balcony or in the garden, please consider the environment and safety. Also make sure to always keep the barbecue on its horizontal part, in a stable condition.

Be careful not to injure yourself with the metal parts of the barbecue (band, handle, window, etc.).

## **For each use, make sure you are always in a sufficiently ventilated area.**

- Adjust the firepower and the holding time with the ventilation window located on the side of the barbecue.

- Fully open the ventilation opening and turn on outside. Please light well before putting it in an indoor room.

- When barbecuing in a room inside a building, ensure that the room is constantly ventilated (to prevent carbon monoxide poisoning.)

- If you use the product with the ventilation port closed, the amount of carbon monoxide generated will increase, so be sure to ventilate.

- Please store the barbecue only when it is completely cool.

- The diatomaceous earth barbecue may crack after use, but there is no problem with use.

- Do not use a bellows to fan the fire as this sends out a lot of air and the charcoal burns heavily, raising the temperature and can quickly damage the barbecue.

- When moving the barbecue, use heavy cotton gloves. Do not use synthetic fibers or rubber gloves as they may melt or catch fire and injure you

- Replace metal accessories if they are severely damaged in order to maintain your safety.

- It is very dangerous to move or transport the stove with lit charcoal, so do not do this.