# **Components & Accessories** Information

ADA Continuous Handrail



## 1-3/8" Handrail

 Available in 8, 10, and 16' Lengths



## Internal Connector

- Internal Connector is used to connect Handrail(s) and Elbow(s)
- Collar Ring included
  Screws included to secure Connector to Handrail



## **Adjustable Elbow**

- User Friendly
- Works from 0° 90°
- (2) Collar Rings included
- Screws included to secure Elbow to Handrail



## Wall Mount

- Used to attach Handrail to wall or post
  - Includes (2) Stainless Steel screws to attach Handrail
- Has (3) ¼" holes for fastening to wall or post (screws included)
- Recommended every six feet



### **Collar Ring**

- Used to cover splice
- Included with Internal Connector, Wall Return, and Adjustable Elbow



## **Internal End Cap**

• Used to cap off Handrail if not returning to a wall or post



### 90° Elbow

- Used for inside corners
- Use (2) of these Elbows to wrap around a 2" or 4" post



## 90° Welded Elbow

Used for outside corners



## Wall Return

- Used to return to a wall or post from Handrail
- Collar Ring included
- Screws included to secure
  Return to wall or post
- Screws included to secure Return to Handrail



### Wall End Mount

- Use when ending into a wall
- Screws included to secure Mount to wall or post
- Screws included to secure Mount to Handrail







Protrudes past a post and returns to the post



**Inside Corner Mount** 

needed on a level area

Screws included

Use with 90° bent Elbow

.

Used when an inside corner is

#### Used for insi Use (2) of th around a 2"

W V

## **Extended Wall Mount**

- Used to attach Handrail to wall or post
- Includes (2) Stainless Steel screws to attach Handrail
- Has (3) ¼" holes for fastening to wall or post (screws included)
- Recommended every six feet