

Wireless Headphones User manual



VIRELESS HEADPHONES

YOUR MUSIC STYLE

MAKE YOUR SPORTS MORE CONCENTRATE

I. NOTICE

Please keep and use this product in a normal temperature

DO NOT expose this product to a damp environment

DO NOT throw or drop this product

DO NOT disassemble, repair, or modify this product

This product has a lithium battery, to avoid danger DO NOT close to the fire

II. KIND REMINDER

- To prolong the headphones life span and to fend off hearing loss, please do not listen to music at high volume for a long time.
- When an error occurs with the headphones, please turn off the product and reboot.
- 3. When the headphones power is low, the Bluetooth range may be affected. Please charge the headphones to avoid disruptions during use.

III. OVERVIEW



Function Keys:

Next song /Increase volume ▶►/+

Short press the "+"button to next song /Long press the "+"button to increase the volume

Previous song /Reduce volume >>/-

Short press the "-" button skip to previous song /Long press the button "-" to reduce the volume

ON/OFF 😃

Press and hold for 3 seconds to turn the headphones ON or OFF

IV. SPECIFICATION

Bluetooth Version: V4.0 Audio Input: Bluetooth, Aux

Receiving range: 10 meters without obstacle

Impedance: 32ohm±10% Driver Unit: 2×φ40mm speaker Working Voltage: 3.7V Sensitivity: 105±5dB at 1KHz Max output power: 30mW

Audio jack: φ3.5mm

Frequence Response: 20Hz-20KHz

Built in Battery: 300mAh/Up to 10 hours music time

Changing time: ≤2.5hours
Talking time: about 18 hours
Standby time: about 200 hours

V. PACKING LIST

- 1. Headphone * 1
- 2. USB cable * 1
- 3. User manual * 1
- 4 AUX cable * 1

VI.BLUETOOTH OPERATION

- 1. Turn the headphone on by pressing the power button for 3 seconds to enter into the pairing mode, the red and blue light would flash alternately, and the headphone would enter Bluetooth searching state automatically. After pairing successfully, the blue light would flash up; but if fail, it would automatically shut down within 5 minutes. If the connection fails, please restart or charge the headphone, since a low battery would cause to shutdown.
- 2. After connecting to the phone successfully, the headphone would beep when there is an incoming call.

VII.AUX OPERATION

- Insert a 3.5mm audio cable into the AUX jack on the back of the headphone. Connect the 3.5mm cable to any audio device with a port.
- Plug the audio line into the AUX audio input of the headphone and other audio devices like computer. The Bluetooth should still be on while plugging an aux line, otherwise, the operations would be invalid.

VIII.Common Problem Solution

	PROBLEM	TROUBLESHOOTING
,	Repeated failure of connection	Make sure the headphone is in searching mode, or try to reboot. Turn off other Bluetooth devices which would affect searching.
	Small or distorted sound	Detect the volume of the headphone, and adjust to an appropriate volume. Low battery, please fully charge and try again.
	Discontinuous music	Move the paired Bluetooth device closer to the headphones. Make sure there are no obstacles between the Bluetooth device and the headphones.
	Bluetooth indicator light does not show up	Low battery, please fully charge and try again. Reboot

Tech Support:
Website: www.otiumobile.com
Email: support@otiumobile.com
Facebook: www.facebook.com/otiumobile

