

Bluetooth Car FM Transmitter

USER GUIDE

Product Description

This device lets you stream music and calls directly from your Bluetooth device to your car FM stereo system. The built-in microphone provides you with an amazing hands free function, it also features a USB and TF card reader that let you stream your favorite MP3 and WMA tunes to your car's stereo system. Using the USB charging port can charge your smart phone and other devices.

Specifications


FM frequency range: 88.1~107.9MHz
Frequency stability: ±10ppm
Product input: 12-24V
USB Charger output: 5V/2.4A
TF slot and USB reader support music format: MP3,WMA
TF and USB flash disk(Max capacity): 32GB
FM operating distance: about 5M

Features

Wirelessly transmit phone call from Bluetooth mobile phone to the car FM stereo system;
Switch to Hands-free mode automatically from music playing status when receiving calls;
Supports music play back from USB and TF card;
USB output to charge for smart phones and other devices(5V/2.4A) With voice prompts.

Product Diagram

- ①Frequency(channel)up
- ②Frequency(channel)down
- ③Multi-function button
- ④Model switch
- ⑤Screen display
- ⑥TF slot
- ⑦Mic
- ⑧USB reader
- ⑨USB output:5V/2.4A



Operation Instruction

Using FM Transmitter function

- 1.Plug the FM transmitter into your vehicle's cigarette lighter or power port.
- 2.Tune you radio to an unused FM frequency,then match the same frequency of this unit (via "CH+"button①and"CH-"button②).
- 3.Insert a USB flash drive into the TF card slot⑥or the upward USB port⑧which containing MP3 files into USB port or memory card slot of this unit accordingly.It will play and transmit the MP3 files automatically.

Pay attention,only the upward USB port⑧can serve as a USB reader!

Using Bluetooth function

- 1.Using Bluetooth for the first time,you need to pair your mobile phone with this unit. Activate your mobile phone's bluetooth function,then search new device.When the mobile phone detects this unit(named as"FM30") , please pair,when pairing is successful, the display screen⑤ will stop flashing.
- 2.Now you can enjoy your music through the car stereo.
- 3.In the music playing mode,when there is an incoming call,this unit will automatically switch to telephone mode.

Bluetooth calling

- 1.Please press the knob③(Multi-function button) to answer incoming call.
- 2.Please press the knob③to hang up a call.
- 3.Please press the knob③twice to dial the last number.
- 4.When making a call,you can only dial the phone number by your mobile phone,but once the call connected,you can use the hands-free function to enjoy it.

Using USB charger function

When this unit powered from car lighter socket,connect the USB port of this unit⑨ to your mobile phone with a special USB cable(not included), this unit will serve as mobile phone charger(5V/2.4A high speed output)

Pay attention,only the downward USB port⑨can serve as a charge USB !

Playing mode switch

This unit have 3 kinds of music source mode(such as bluetooth 、 TF card 、 USB flash disk),short press"M"button④ switch different music source mode and choose your favorite music source mode.Pay attention! this Unit will be preferential admit later connected device.This unit also has various playing models such as single,order circulation,and random mode,keep long press"M"button④can make choice.

NOTE

- 1.The transmitter will connect to the pre-set phone automatically when turns on. (Keep mobile phone's bluetooth activate).
- 2.For the best audio quality, please turn the volume of the cell phone and FM transmitter into the max level.
- 3.If the noisy is too loud, please try other FM frequency.
- 4.The transmitter will power off automatically without any operation in 5 minutes,you need to press the Multi-function button for 2 seconds to turn it on.
- 5.Never dismantle the product without due permission,otherwise it may nullify the warranty clause.

Quick Guide

| Operation Guide | On FM transmitter |
|----------------------------|--|
| 1.Answer/hang up the call | Press knob③(Multi-function button): answer the call Press knob③: hang up the call |
| 2.Play and Pause the music | Press knob③: play the music Press knob③: pause playing |
| 3.Set frequency | Press"CH+"button①: increase the frequency Press"CH-"button②: decrease the frequency |
| 4.Choose music | Rotate knob③ in clockwise:Play the next song Anticlockwise:Play the previous song |
| 5.Adjust the volume | Long hold rotate knob③in clockwise to increase volume anticlockwise to decrease volume |
| 6.Reject a call | Press"CH+"button①or Press"CH-" button② |
| 7.Power off FM transmitte | Keep long press knob③ more than 5 seconds |



Please read this manual carefully before use.