



Set Up Instructions

WLM-PANEL CONNECTION

FEET




WLM-P-22E



WLM-P-22R



WLM-P-22L



WLM-P-22E

CLAMPS

