

RTD Installation

When you un-box the RTD Replacement Kit, make sure you have, and can identify all of the following parts:

- (1) 7" RTD Temperature Sensor Rod (P/N BAC194)
- (1) Screw (1/2" long)
- (1) Lock Nut

The easy installation process includes:

- 1) Unplugging the grill.
- 2) Partially removing the existing Digital Control.
- 2) Installing the RTD.
- 3) Re-mounting the Digital Control.

Follow the following step by step instructions and you'll be cookin' in no time!



