



BALANCE BALL® CHAIR LEG EXTENDERS

Setup Guide

Please read before setting up or using your Balance Ball® Chair Leg Extenders.



STEP 1

Remove the caster wheels from the base of the chair. Insert the Leg Extenders into the holes making sure the metal connection point goes in the deepest hole and the two plastic connection points go into the shallow holes.



STEP 2

Push the Leg Extenders firmly into the base until they are securely pressed up against the chair base.



STEP 3

Insert each of the 4 caster wheels into each of the Leg Extender holes.



STEP 4

Push the caster wheels firmly into the Leg Extenders until they are securely attached.

Gaiam Leg Extenders are only compatible with the Gaiam Classic Balance Ball Chair and the Gaiam Backless Balance Ball Chair.