



STAY-N-PLAY BALL

Setup, Usage Tips, and Care & Safety Guide

Please read before setting up or using your Stay-N-Play Ball.

TOOLS NEEDED

1. Stay-N-Play Ball pump (you may want to use a bicycle pump or compressor for initial inflation).

SETUP


1. Remove Stay-N-Play Ball from box and check for shipping damage. (Note: it is normal for balls to have slight creases or fold marks when first inflated.)
2. Allow ball to reach room temperature before inflating.
3. Insert tip of pump into hole in Stay-N-Play Ball. Inflate ball to the desired height and firmness. DO NOT overinflate.
4. Remove pump from ball and immediately insert plug into hole (so head is flush with surface of ball). DO NOT overinflate.
5. To measure the correct inflation of your ball. Please measure the diameter of the ball to 17.71 inches as shown below..
6. Your Stay-N-Play Ball is now ready for use.

INFLATION NOTICE

- Inflate ball and plug.
- Ball may not inflate to 100% of size on initial inflation.
- Wait 24 hrs.
- Deflate 50% and inflate again.
- Due to the ball's material, the ball will increase to proper size with second inflation.

RECOMMENDATION

Recommended for children ages 5 - 7 ranging in heights from 45" - 50".



SIZE

45cm Balance Ball with four built-in prongs so it wont roll away.



WARNING
CHOKING HAZARD
SMALL PARTS. NOT FOR
CHILDREN UNDER 3 YRS.



GAIAM®

STAY-N-PLAY BALL

Setup, Usage Tips, and Care & Safety Guide

Please read before setting up or using your Stay-N-Play Ball.

IMPORTANT SAFETY CAUTIONS!

Please read before setting up or using your Stay-N-Play Ball.

1. Always use the Stay-N-Play Ball in an open area free of furniture or other items that could get in the way during use.
2. Use Stay-N-Play Ball only on smooth surfaces. Do not use ball if deep scratches or gouges exist.
3. Stop and rest if you feel dizzy or short of breath.
4. This product is sold without any warranties or guarantees of any kind and manufacturer and distributor disclaim any liability, loss or damage caused by its use.
5. Intended for sitting, DO NOT stand or kneel on ball.
6. Do not leave child unattended while using the Stay-N-Play Ball.
7. Ball is designed to be used by one child at a time.

CARE

1. Clear play area of sharp objects that may puncture ball. Use only on a smooth surface.
2. It is not necessary to deflate ball after use; however, slight leakage may occur over time. Re-inflate when necessary.
3. Hand wash ball with a soft cloth and warm soapy water. Do not use harsh or abrasive chemicals or cleaning tools that may scratch or damage ball.
4. Always check the ball for nicks or scratches before each use. If damaged in any way, do not use.
5. Avoid placing or rolling ball on newspaper, photocopies or other materials printed in ink as ink may permanently mark ball.
6. Avoid exposing ball to rough, sharp or abrasive surfaces, or to heat or excessive sunlight.
7. This product is sold without any warranties or guarantees of any kind the manufacturer and distributor disclaim any liability, loss or damage caused by its use.

CAUTION: DO NOT place Stay-N-Play Ball in contact with woodwork, wood furniture or painted walls for any period of time. Damage to finish may occur.

SEE MORE AT WWW.GAIAM.COM