


miamily
A SWISS BRAND

HIPSTER™

INFANT INSERT

I N S T R U C T I O N S

M A N U A L



HOW TO USE

1. Zip on the double shoulder attachment to the hip seat so it's ready for use.
2. Put the infant insert on a flat surface, place your baby inside the infant insert and secure your baby inside insert using the T front strap by clipping in the closure snaps on the sides. There are two snaps on each side, adjust accordingly to your baby's size.
3. With both hands, lift the infant insert with your baby securely inside and place the infant insert on the hip seat with your baby facing you.

NEVER use the infant insert in the forward facing position.

4. With one hand supporting the infant insert, put on the carrier by sliding the double straps over your shoulders.
5. Secure the carrier by clipping in the back safety buckle.
6. There are two sets of security loops on the infant insert, please attach the side loops to the double shoulder black webbing on the side of the waist and secure the top security loops to the double shoulder padded straps near the shoulder.
7. For step by step video instructions, please visit www.miamily.com/instructions

HOW TO ADJUST FOR OPTIMAL FIT

- * Adjust the carrier by pulling on the front and back adjustable shoulder straps so that your infant sits snugly in the infant insert with his tummy and chest against your body. Baby should not slump down (If you place your hand behind baby's back and press gently, baby should not uncurl or move closer to you).
- * Leg position of the baby will vary depending on the size of your baby. For newborn, bend baby's knees so it's in a fetal position and therefore not sticking out of the infant insert. For bigger infants, rest baby's legs on the seat cushion so his thighs are supported by the cushion at hip level and legs are sticking out of the infant insert.

SAFETY CHECKS

- ✓ Keep a tight fit. Infant Insert should hug your baby tightly. A loose fit will allow your baby to slouch down which might hinder baby's breathing.
- ✓ Keep baby close. Baby's head should be just under your chin, close enough to kiss.
- ✓ Keep baby's face in view at all times. Baby's face should never be covered by the infant insert.
- ✓ Keep baby's chin off their chest. Ensure there is always at least a finger's width under baby's chin to avoid your baby from looking downwards and resting his chin on his chest which can restrict breathing.



1. Ergonomic angled seat cushion
2. Additional head and neck support
3. T-front strap
4. Closure snaps
5. Security loops
6. Soft cotton inner layer
7. Breathable mesh outer layer
8. Reinforcement loops

IMPORTANT SAFETY TIPS AND INFORMATION:

IMPORTANT! KEEP INSTRUCTIONS FOR FUTURE REFERENCE.

- The MiaMily Infant Insert is designed so you can carry your infant from birth. The infant insert wraps around your infant to provide the proper head and neck support and to ensure your infant's legs and hips are positioned properly. MiaMily infant insert is designed specifically for MiaMily carriers and should only be used with MiaMily carriers.
- MiaMily Infant Insert can only be used in the facing in position (Never use the infant insert in any other positions such as forward facing, back carry, or hip carry).
- Extra padding has been added to the top edge of the Infant Insert. For extra neck support, fold the round of backwards.
- The angled base is designed so that infant's knees rest higher than the hips to imitate the natural fetal position and for healthy hip development. As baby grows, the leg position will change and the knees will be at the hip level. The shape of the base allows room for the feet to rest comfortably without being pushed against the caregiver's body.
- Recommended age and weight limit is 0-4 months and 7-12 lbs (3.2 kg and 5.5 kg), however every baby develops differently so as long as baby does not have strong head or neck support, continue using the infant insert.
- Always check to make sure there is at least room for 2 fingers under infant's chin. Make sure infant's airway is always clear and infant is breathing normally. Infant's chin should never rest on infant's chest at that can close infant's airway. Make sure infant is close enough to kiss. Always check infant constantly. Premature infants, infants with respiratory problems and infants under 4 months are at greater risk of suffocation.
- Check if there is any damage or rips to the Infant Insert. Do not use if Infant Insert is damaged.
- Check Infant's position regularly, making sure that infant is not slumping downward or have their chin on their chest. Infant's hands and legs should be free and not constricted.
- Use Infant Insert only with the carrier, never on it's own. Never leave a baby sleeping in the Infant Insert.

WARRANTY

MiaMily warrants that our products are free from any manufacturing defects in material or workmanship for a period of one (1) years from the original date of purchase. If you are in need of warranty or repair for a MiaMily product, please contact us at questions@miamily.com

HIPSTER™ Care


Machine washable. Cold wash in gentle cycle, air dry

▲ WARNING

FALL AND SUFFOCATION HAZARD

FALL HAZARD - Infant can fall out of infant insert. Take special care when leaning or walking. Use HIPSTER™ Infant insert for infants between 7 lbs. (3.2 kg.) and 12 lbs. (5.5 kg.) with the HIPSTER™ Carrier and the infant should only be carried in the front- carry position.

SUFFOCATION HAZARD - infants under 4 months can suffocate in this product if face is pressed tight against your body. Keep infant's face free from obstructions at all times.



www.miamily.com