

### **IMPORTANT!**

Before you operate your  $\ensuremath{\mathsf{Quad}}\xspace \ensuremath{\mathsf{Socoler}}\xspace$  , please read carefully:



Do not ride this scooter until you read and thoroughly understand the owners manual. It contains information critical to your safety. If you have any questions about the operation of the scooter, you should consult your authorized dealer.



It is extremely important that you follow the safety guidelines contained in this manual in order to ensure maximum safety.



Failure to comply with the standards outlined in this manual could result in fire and/or serious injury.



RMB EV is not liable for any damage or injuries caused by unsafe or faulty repairs. Any repairs made to this product by unauthorized service technicians are the sole responsibility of the owner.



Our products are designed to be ecologically conscious, please dispose of used batteries in compliance is with local laws.

Never charge scooter longer than 10 hours. If the charger does not turn green by 10 hours or you smell a Sulphur odor after a long charge there is a problem and contact the dealer for instructions.

# RMB EV

e-Quad XL Scooter



## Owner's Manual

3362 Fulton RoadFulton, CA 95439 USA Tel:(707)568-3388 Fax:(707)526-1409 www.rmbev.com

List of Parts Assembling The Quad Scooter E-QUAD XL E-QUAD XL



Model no.	RMB e-Quad XL
Product size	57L*36W*35H inch 1450*920*880mm)
Type of motor	DC brushless motor
Motor power	48V 800W
Battery type	Sealed lead acid battery
Battery capacity	48V 20Ah
Charger	110V-240V,UL Approved
Charging time	6-8 hours
Max. speed	Up to 15MPH (24km/h)
Single charge	Up to 15MILES (24km)
Max capacity	500LBS (129kg)
Net weight	255LBS (116kg)





20. Forward/reverse switch

1. Instrument 10.Floor mat

3.Seat

9.Motor

- 2.Handlebar 11.Battery
  - 12.Front wheel
- 4.Armrest 13.Spotlight
- 5 Basket 14.Shock absorption
- 6. Shock absorption 15. Foldable structure
- 7.Rear fender
- 8. Rear wheel 17.USB port
- 24. High-low speed switch
- 16.Lock mechanism switch 25.Front basket

22. Breaker

19. Horn switch

21. Twist throttle

23. Charger port

- 26. Auxiliary seat handlebar
- 18. Headlight switch

1. Put the seat in the specified position, and then tighten A and B with bolts provided. Turn the screw to fasten the seat rear part by hand before assembling the basket.





- 2.Put the auxiliary seat handlebar in the specified position, and then tighten with bolts provided.
- 3. Extend the handlebar tube to full upright position, and slide it into connecting with the front fork. Ensure that the handlebar is facing front, the brake on the left side and the throttle on the right, then tighten the handlebar tube collar clamp using the enclosed 5mm wrench provided.
- 4 Before assembling the basket,plug in A and B, and then install four bolts provided well.





Before driving the scooter, please open the switch(A).If not using the scooter for a long time, please close this switch to prevent electric loss.



The Limited Warranty does not cover or apply to the following: Normal wear and tear; any damage, failure and/or loss caused by accident, misuse, neglect, abuse and/or failure to follow instructions or warnings as stated on the product or in the applicable owner's manual or other printed materials provided with the product; damage, failure and/or loss caused by the use of the product in any other manner for which such products were not specifically designed.

RMB EV warrants the e-Quad for six (6) months according to the following terms. Batteries and tires are warranted for three (3) months. This warranty extends to the original retail purchaser only and commences on the date of the original retail purchase. Any part of the RMB EV product manufactured or supplied by RMB EV and found in the reasonable judgment of RMB EV to be defective in material or workmanship will be repaired or replaced by an authorized RMB EV service dealer without charge for parts or labor. RMB EV is responsible for the expense of delivering the warranty replacement parts. However, if the customer chooses not to replace the parts, the expense of delivering the e-Quad to the factory / authorized service dealer for warranty work or the expense of returning it back to the owner after repair/ replacement will be paid for by the owner.

RMB EV's responsibility in respect to claims is limited to making the required repairs or replacements and no claim of breach of warranty shall be cause for cancellation or rescission of the contract of sale of any RMB EV product. Proof of date of purchase will be required by the dealer to substantiate any warranty claim.

3

An authorized RMB EV service dealer must perform all warranty work. The warranty is limited to thirty (30) days from the date of purchase for any RMB EV product that is used for rental demonstration, commercial purposes, or any other income producing purpose. This warranty does not cover any RMB EV product that has been subject to misuse, neglect, negligence or accident, or has been operated in any way contrary to the operating instructions as specified in RMB EV's owner's manual. This warranty does not apply to any damage to RMB EV products that is the result of improper maintenance or to any RMB EV product that has been altered or modified so as to adversely affect the products operation, performance, or durability, or that has been altered or modified to change its intended use. This warranty does not extend to repairs made necessary by normal wear and or by use of parts that are incompatible with RMB EV products. In addition this warranty does not cover items that experience normal wear and tear.

#### WHAT RMB EV WILL DO:

RMB EV will, at its sole option, either repair, replace or refund the purchase price of any unit that does not conform to this limited warranty. RMB EV may choose at its option to use functionally equivalent reconditioned, refurbished or new units or parts or any units. You are responsible to get the unit back to RMB EV.

#### HOW TO GET WARRANTY SERVICE:

To obtain warranty service, please call or fax to the following telephone numbers for RMB EV Customer Service - warranty repair

Tel. 1-707-568-3388 or Fax.1-707-526-1409, Email: info@rmbev.com

#### DO NOT RETURN YOUR PRODUCT TO ANY ADDRESS.

Please call, email, or write for the location of the RMB EV authorized service center nearest you and for the procedures for obtaining warranty claims.

#### Spare battery

1.Lift seat, place spare battery pack onto optional bracket assembly and bolt bracket to battery pack.



2.Plug in A and B, and then connect the spare battery well.

- 5 ----- 6 -----