

## CLASSIC CHAIR POCKET SIZING CHART

## **PLEASE NOTE:**

It is VERY IMPORTANT to measure BOTH the TOP AND BOTTOM of the chair back! You will need both measurements to correctly size your Aussie Pouches.



CLASSIC Size	Width of Chair Back TOP (inches)	Width of Chair Back BOTTOM (inches)
ANGLE 11"	10" or less	14" or less
ANGLE 13"	10"-12"	14"-16"
Original 13"	10"-12"	10"-12"
Medium 15"	12"-14"	12"-14"
Large 17"	14"-16"	14"-16"
X-Large 19"	16"-18"	16"-18"
Jumbo 21"	18"-20"	18"-20"