

Dolphin™


Water-Resistant Remote Control

INSTALLING THE DOLPHIN REMOTE CRADLE

The Dolphin cradle may be installed in the house or outside by the spa. If installed outside, be sure that the cradle is protected from direct sunlight and constant exposure to moisture.

How to install:

1. Measure hole placement. Holes should be drilled 3" apart.
2. Drill holes using a 3/16" drill bit.
3. Place one wall insert into each hole.
4. Holding the cradle in place, tighten the screw into the wall insert.



Note: If the cradle is mounted onto a wood surface, inserts and a pilot hole may not be necessary.

