

moving your mannequin



1. Never drag your mannequin.
2. It is recommended to remove the mannequin from its base before its moved.
3. Direct contact with the floor may lead to chipping, dirt, and damage to most focal parts of your mannequin.
4. When moving the mannequin to a new location, be sure to remove the arms and leg before relocating the mannequin. If they drop, the hands, arms, and leg may be damaged.