

# Pink Power<sup>®</sup>



## CORDLESS

SCREWDRIVER&LEVEL KIT



GENERAL INSTRUCTION MANUAL



PP481-LK

# Thank you for your purchase from Pink Power!

We hope our tools will help you with any project you approach, whether you are building a deck or just hanging a picture. We designed our tools specifically for women and hope they will help you complete your tasks. We are proud of our Pink Power line and happy to offer you quality tools.

All of our tools come with a full 2 year warranty. If any damage occurs to your tool, battery or charger just reach out to us using the information below and I will replace your tool at no cost to you. We greatly appreciate your business.

Thank you,

*Michael Wilson*



## Warranty Information

Full 2 years against ANY defects or damage

1.888.989.7249

[customerservice@pinkpowerdrill.com](mailto:customerservice@pinkpowerdrill.com)



## DESCRIPTION

1. Quick-Loader With 6 Bits
2. 2 Position Rotary Handle
3. On/Off/Forward/Reverse Switch
4. LED Work Light
5. LED Battery Power Indicator
6. On/Off Trigger

**PinkPower®**

# INSTRUCTIONS

Choose a bit by lifting it forward.



Insert the bit into the shaft of the screwdriver



## UNLOADING THE BIT

Pull the bit out from the shaft and snap back into place.



## TO ROTATE THE SCREWDRIVER HANDLE:

Press and hold the button on the 2 Position Rotary Handle **2** on top of the screwdriver and rotate the handle clockwise until it locks into place as shown above.



## SCREWING/UNSCREWING:

Your screwdriver is equipped with an On/Off/Forward/Reverse Switch **3** to change the rotation of your chuck.

1. To screw in/forward, press the the side of the Lock/Forward/Reverse Switch **3** marked "R" all the way in, then press the On/Off Trigger **6**.
2. To unscrew/reverse, press the the side of the Lock/Forward/Reverse Switch (3) marked "L" all the way in, then press the On/Off Trigger **6**.

## CHARGING YOUR TOOL

Plug the power supply into the screwdriver's internal battery pack (located on the bottom of the handle). The RED light on the LED Battery Power Indicator **5** will illuminate while charging. Allow 5 hours to fully charge.

## CHECKING THE BATTERY LEVEL OF YOUR TOOL

Your screwdriver is equipped with an LED Battery Power Indicator **5** consisting of 3 LEDs. While using your tool, you can press the battery indicator button to check the power of your screwdriver. When all 3 lights are on, your tool is fully charged. When only the YELLOW and RED light are on, your screwdriver is at 50% charge. When only the RED light is on, your tool has less than 25% charge remaining and should be recharged.



# TOOL SAFETY

## SAFETY

Do not use power tools under the influence of medication, drugs or alcohol as this could result in serious personal injury. Keep hair, clothing, jewelry and other loose objects away from moving parts. Use the proper safety equipment when operating power tools. This may include eye or dust protection equipment.

The power tool plugs should never be modified in any way as this could increase the risk of electric shock or malfunction. The tool should be in a locked state when not in use.

Do not force use of the power tool. Make sure to always ensure proper balance when using power tools. If your tool is damaged stop use immediately.

## WORKING AREA

Keep working area clean and well lit. Cluttered and dark areas can lead to accidents. Do not operate power tools in explosive atmospheres, such as in the presence of flammable liquids, gases or dust. Power tools create sparks which may ignite fumes and dust.

## CLEANING AND MAINTENANCE

Remove dust and dirt with a cloth slightly dampened with solution. In doing so, ensure that no water gets into the inner drill. Clean drillings and dust out of the chuck regularly. The drill is permanently lubricated and does not require oiling.

## BATTERY USE AND CARE

Only use the included charger to charge your battery. Not using the correct charger could cause injury or damage to your tool. Abuse of the tool can lead to battery leakage. Avoid contact with battery fluid. If contact occurs, seek medical help immediately. Never attempt to open the battery for any reason. Only charge and store the battery between temperatures of 39°F and 70°F.

## DISPOSAL OF BATTERY

To preserve natural resources please recycle or dispose of the battery properly. This product contains lithium batteries. Consult your local waste authority for information regarding available recycling and/or disposal options.

### TECHNICAL DATA

Rechargeable battery	3.6V
No-load speed	200 RPM
Drill chuck capacity	1/4"
Charge time	5 hours
Charger rating input:	120V-60Hz
Charger rating output:	6V DC 300mA

**PinkPower®**  
[WWW.PINKPOWERDRILL.COM](http://WWW.PINKPOWERDRILL.COM)