

# PinkPower®

POWERFUL TOOLS FOR POWERFUL WOMEN

## 3.6-VOLT ELECTRIC SCREWDRIVER



**PP481-LK**

## Thank you for your purchase!

Ever since we started back in 2011, our mission has been to give YOU the confidence to tackle something new. Whether you're building a deck or just hanging a picture, we'll be there along the way. We stand behind every product, which is why they come with a full 3-year warranty. Our contact information is listed below and you can reach out to us any time. From the entire Pink Power family, we wish you all the best on your next project!

Thank you!

*Michael Wilson*

## Need to get in touch?

Register Your Warranty and sign up for free coupons:  
[Pinkpowerdrill.com/warranty](https://pinkpowerdrill.com/warranty)

## Questions?

📞 Call or Text Us: **813.304.2224**

✉️ Email Us: [customerservice@pinkpowerdrill.com](mailto:customerservice@pinkpowerdrill.com)


## Love your items so much that you want to be a Brand Ambassador?

Join the Pink Power Army by sending your request to:  
[affiliate@pinkpowerdrill.com](mailto:affiliate@pinkpowerdrill.com)

## Follow us for discounts and fun!



@shoppinkpower

 [pinkpowerdrill.com/blog](https://pinkpowerdrill.com/blog)



# 3.6-VOLT ELECTRIC SCREWDRIVER

## FEATURES:

- 1 Quick-loader with 6 Bits
- 2 2 Position Rotary Handle
- 3 Forward/Reverse Switch
- 4 LED Light
- 5 Battery Power Gauge
- 6 ON/OFF Trigger



## OPERATING INSTRUCTIONS:

### CHARGING YOUR TOOL

Plug the power supply into the screwdriver's internal battery pack (located at the bottom of the handle). The Red light on the Battery Power Gauge will illuminate while charging. Allow 3 hours to fully charge. Once your tool is charged, you must unplug the power supply before using your tool.

### BATTERY GAUGE

Your screwdriver is equipped with a Battery Power Gauge on the top of the screwdriver. While using your tool, you can press the Battery Power Gauge button to check the power of your screwdriver. If all 3 lights are illuminated, your battery is fully charged. If 2 lights are illuminated, your battery is at 50% charge. If just one light is illuminated, you need to recharge the screwdriver.

### SCREWING & UNSCREWING

Your screwdriver is equipped with a Forward/Reverse Switch to change the rotation of your chuck.

- To screw in/forward, press the side of the Forward/Reverse Switch marked "R" and then press the ON/OFF Trigger.
- To screw unscrew/reverse, press the side of the Forward/Reverse Switch marked "L" and then press the ON/OFF Trigger.

### LOADING & UNLOADING THE BIT

Choose a bit by lifting it forward, then insert it into the shaft of the screwdriver. To unload, pull the bit out from the shaft and snap it back into place.



### ROTATING THE SCREWDRIVER HANDLE

Press and hold the button on the 2 Position Rotary Handle on top of the screwdriver and rotate the handle clockwise until it locks into place as shown on the right.



### LED LIGHT

Your screwdriver comes with an LED light that will automatically turn on when the trigger is pulled. This helps when working in dim areas such as a closet or cabinet.

Prefer video tips instead? Go to [Pinkpowerdrill.com/Videos](https://pinkpowerdrill.com/Videos)



## TOOL SAFETY:

### SAFETY

Do not use power tools under the influence of medication, drugs, or alcohol as this could result in serious injury. Keep hair, clothing, jewelry, and other loose objects away from moving parts. Use the proper safety equipment when operating power tools.

Never modify your tools as this could increase the risk of electric shock or malfunction. Make sure to always ensure proper balance when using power tools. If your tool is damaged stop use immediately.

### WORKING AREA

Keep your working area clean and well lit. Cluttered and dark areas can lead to accidents. Do not operate power tools in explosive atmospheres such as in the presence of flammable liquids, gases, or dust. Power tools create sparks which may ignite fumes and dust.

### CLEANING & MAINTENANCE

Ensure that the screwdriver is not plugged in before cleaning. Remove dust and dirt with a slightly damp cloth. Ensure that no water gets into the inner parts of your tools, battery, and charger. Your tool is permanently lubricated and does not require oil.

### BATTERY USE & CARE

Only use the included charger to charge your battery. Using the incorrect charger could result in injury or damage to your battery. Do not leave battery and charger unattended when charging. Once the battery is fully charged, remove it from the charger. Abuse of the tool can lead to battery leakage. Avoid contact with battery fluid. If contact occurs, seek medical help immediately. Never attempt to open the battery for any reason. Do not expose your battery to rain or wet conditions. Do not store your battery in temperatures below 39°F or above 70°F.

## TECHNICAL DATA:

**Rechargeable battery:** 3.6V

**No-load speed (RPM):** 200

**Drill chuck capacity:** 1/4"

**Charge time:** 2-3 hours

**Charger rating input:** 100-240V AC 50/60HZ

**Charger rating output:** 5V DC 700mA