

# 2019 - 2022 RANGER BRAKE LIGHT INSTALL GUIDE

## STEP 1

Be sure that there is no power going to the brake lights.

Remove two size 8mm bolts from your truck.




There are two tabs located at the top and bottom of the side of your housing. Pull away from the side of your truck with moderate force to release these tabs

## STEP 2

Remove your Brake light socket from the housing using a clockwise turn.

*\*The brake bulb is the top bulb in the housing\**



## STEP 3

carefully remove the OEM glass bulb by pulling away from the base of the bulb.

*\*Make sure this bulb is not hot when removing the bulb\**





## STEP 4

Insert your  
F150LEDs.com Brake  
bulb.

**Test your bulb, if the  
bulb does not light  
then remove the bulb  
and rotate it 180  
degrees.**



Text for support: 706-214-2618

Visit our site to chat: [www.F150LEDs.com](http://www.F150LEDs.com)  
or email [CustomerSupport@F150LEDs.com](mailto:CustomerSupport@F150LEDs.com)

