

2019 - 2022 RANGER REVERSE BULB INSTALL GUIDE

STEP 1

Be sure that there is no power going to your Reverse lights.

Remove two size 8mm bolts from your truck.

There are two tabs located at the top and bottom of the side of your housing.

Pull away from the side of your truck with moderate force to release these tabs



STEP 2

Remove your Reverse light socket from the housing using a clockwise turn.

the reverse bulb is the lowest bulb in the housing



STEP 3

carefully remove the OEM glass bulb by pulling away from the base of the bulb.

Make sure this bulb is not hot when removing the bulb





STEP 4

Insert your
F150LEDs
reverse bulb.

*Test your bulb, if
the bulb does not
light then remove
the bulb and rotate
it 180 degrees.*





STEP 5

Reinsert the bulb back into the housing using a clockwise turn to lock it into place then reinstall your taillight assembly.



Text for support: 706-214-2618

Visit our site to chat: www.F150LEDs.com

or email CustomerSupport@F150LEDs.com

