


## Button Functions



### INCLUDED

- Bluetooth active noise-cancelling headset X1
- Manual X1
- 3.5 mm—3.5 mm audio cable X1
- USB M — c charging cable X1

### ANC (ACTIVE NOISE CANCELLING) BUTTON

To turn on ANC:

- Switch the ANC button up to turn on active noise cancelling
- The green LED light will turn on
- The ANC function is available in both wired and wireless mode

To turn off ANC:

- Switch the ANC button down to turn off active noise cancelling
- The green LED light will turn off
- The ANC function must be switched off by manual operation

### MULTIFUNCTION BUTTON

To Turn On Bluetooth:

- To switch on, press and hold the Mutli Function Button (MFB) for about 3 seconds
- The headphones will enter Bluetooth searching mode
- The blue and red indicator lights will start to flash alternately

To Turn Off Bluetooth:

- To switch off, press and hold the MFB for about 3 seconds.

*\*The headphones that has been previously paired with another device will automatically connect with the device if the device is powered on and within connecting range. If the headphones have not been previously paired, it will enter standby mode with a continuous blue light.*

For Phonecalls:

- To make a call, quickly press the MFB twice to call the last number in the call list
- To answer a phone call, quickly press the MFB button
- To reject a phone call, long press the MFB for about 1.5 seconds
- To end a phone call, short press the MFB during the call
- If you receive or make a call while listening to music, the music will pause until the call ends

To Play/Pause Music:

- To play a song, select the music player and press the Play/Pause key on the headphones
- To pause or resume playing a song, press the Play/Pause key
- To select the next song during playback, press and hold “ + ” button for 2.5 seconds
- To select the previous song, press and hold “ - ” button for 2.5 seconds.

### VOLUME +/- BUTTON

- Turn the volume up or down by a quick press of the volume +/- button during a call or while listening to music
- When the volume reaches maximum volume, there will be a warning tone

### BLUETOOTH INFORMATION

- You can listen to music from a compatible Bluetooth device as well as make and receive hands-free calls with your compatible mobile phone
- They should be within 10 meters (33 feet) of each other
- The headphones are compliant with the Bluetooth Specification 5.0 support the following profiles: Headset Profile (HSP) V1.6, Hands-free Profile (HFP) V1.5, Advanced Audio Distribution Profile (A2DP) V1.0, and Audio Video Remote Control Profile (AVRCP) V1.4 input rating 5V DC, 0.5A

## How to Charge

### STEP 1

Use the provided USB-C cable and connect the end into the USB-C port under the left ear-cap of the headphone.

### STEP 2

Connect the other end of the USB-C cable into a power adaptor (not provided) or a USB charging port.

### STEP3

The indicator light will turn red while charging. Once the device has been fully charged, the indicator light will turn blue. Charge time is approximately 3 hours on an empty battery.

### PASSIVE MODE

- You can use KOVE KIVORI as a wired headphone to conserve battery power
- Simply connect one end of the 3.5mm audio cable to the bottom of the left ear cup and to your device.
- Inserting an audio cable will disable the wireless functionality

### LOW BATTERY WARNING

- When the battery is running low, there will be a warning beep every 60 seconds
- When the battery is running very low, the headphones will switch off automatically

*\*When using the headphones on an airplane, please use the two pins aircraft adapter.*

## Caution

- Please do not have the volume all the way up when turning on your headphones
- Do not turn the volume up suddenly (Slowly adjust the volume to the desired level)
- Do not expose yourself to prolonged listening at high volumes
- If tinnitus (ringing in the ears) occurs, turn the volume down or stop playing

*\*Please follow these steps to avoid hearing damage that can be caused by listening at high volumes.*

- These headphones are designed to block out ambient sound and noises, allowing your ears to focus on what you are listening to
- For this reason, do not operate a vehicle while wearing these headphones
- Do not use these headphones in dangerous environments or in places where hearing ambient sounds is vital.

- During a prolonged period without use, please turn off the headphones and put them back into their case to avoid damage, scratches or bracket deformation
- You should also charge the battery every 6 months to prolong the battery service life
- When resuming use after a long period of time, please charge the headphones first.
- Please store your headphones in a dry environment where the temperature does not exceed 140° F.
- Please do not attempt to access or change the battery of the headphones.

## Tech Specs

Driver unit: 40mm  
Impedance: 32Ω  
Driver unit Frequency: 20Hz-20KHz  
Headphones Sensitivity: 97dB±3dB  
Microphone Sensitivity: -38dB±3dB  
Bluetooth Edition: Bluetooth V5.0  
Radio Frequency Coverage: 2.402GHZ-2.480GHZ  
Transmit Range: about 10m (barrier free)  
Frequency Response: 20HZ-20KHZ  
Active Noise Cancelling: up to 22dB±3dB during 100-1000Hz  
Status Indication: Blue LED flash slowly (under Bluetooth mode)  
Pairing products: Bluetooth computer with HFP, A2DP, AVRCP  
Bluetooth protocol, USB Bluetooth adapter, Bluetooth cell phones, etc.  
Battery: Rechargeable lithium ion battery; 3.7V, 800mAH  
Charge: Computer USB interface, output  
DC 5V/300Ma charger  
Charging Time: more than 2.5 hours  
Play Music/Call Time: Up to 32 hours (Bluetooth & ANC ON)  
Play Music/Call Time: Up to 45 hours (only Bluetooth on)  
Standby Time: Up to 750 hours

# KOVE



SCAN HERE FOR A VIDEO TUTORIAL

## KIVORI

ACTIVE NOISE CANCELLING  
BLUETOOTH HEADPHONES



A STEP BY STEP GUIDE TO:

# CONNECTING YOUR DEVICE

DEVICE: KIVORI

## 01 STEP ONE

Ensure that your Bluetooth device is switched on and that the Bluetooth Mode is enabled.

DEVICE: KIVORI

## 02 STEP TWO

When pairing for the first time, switch on the headphones. The headphones will enter pairing mode and the blue and red indicator light will start to alternately flash until pairing is complete. If your headphones have been previously paired with a different device, ensure that device is switched off, as your headphones will attempt to connect with it automatically.

To connect the headphones to the phone or Bluetooth devices that you have last used with it, switched on the headphones or make the connection in the Bluetooth menu of your device.

DEVICE: KIVORI

## 03 STEP THREE

Activate the Bluetooth feature on your phone or Bluetooth device and set it to search for Bluetooth devices.

DEVICE: KIVORI

## 04 STEP FOUR

Select “KOVE KIVORI” from the list of available bluetooth devices on your phone or Bluetooth device.

DEVICE: KIVORI

## 05 STEP FIVE

When successfully paired, the red and blue lights will turn to a continuous blue light.

To disconnect the headphones from your device, switch off the headphones, or disconnect it in the Bluetooth menu of your device.

DEVICE: KIVORI