Ollo Inground or Wall Light Installation Instructions



		Product Specificati	ons	
Model No.	HV19072T-BR	HV19072T-AB	HV19072T	HV19072T-GPH
Name	Ollo			
Material	316 Stainless Steel + Brass	316 Stainless Steel + Brass	316 Stainless Steel	316 Stainless Steel + Brass
Colour	Face - Brass Body - 316 Stainless Steel	Face - Antique Brass Body - 316 Stainless Steel	316 Stainless Steel	Face - Graphite Body - 316 Stainless Steel
IP Rating	IP65			
Input Voltage	12v DC			
Protection Class	(Low Voltage) 🕪			
Installation Type	Inground or Wall - Recessed			
Lamp Base	MR16			
Lamp Wattage	1x 5w (Maximum - 20w)			
Colour Temp	TRI Colour - 3000k, 4000k, 5500k			
Lumens	270lm, 285lm, 300lm			
CRI	> 80			
Wiring	Parallel			
Dimmable	No - Not with supplied globes			
Warranty	3 Years Replacement*			

Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- · Ensure all electrical mains are disconnected before any installation.
- · Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- · When installing low voltage fittings, Voltage to fitting must be within +or- 5% of voltage required, if not within this allowance warranty will be voided.
- · Aluminium and 304SS fittings must not be installed within 5km of any salt water environments
- When installing copper fittings, gloves must be worn to avoid any oils transferring to fitting.
- All 316 stainless steel fittings must have regular cleaning maintenance to avoid any tea staining from forming on fitting. (Warranty does not cover Tea Staining)
- All o-rings and seals must be in place correctly to maintain warranty
- · This form may be updated at any time due to product improvements, please check online installation form for most current version.

Dimensions

Steps for Installation:

- 1. Make sure that the electrical circuit is free of voltage (master switch off)
- 2. Make a hole where fitting is to be placed using dimensions provided on line drawings, making sure adequate drainage is allowed.
- 3. Insert canister, and ensure that the top is level with wall or ground. Failure to do so will void warranty.
- 4. Using an appropriate 12v DC LED Driver DO NOT CONNECT LIGHT FITTING DIRECTLY TO 240V
- 5. Connect the cable If more than one fitting installed, wiring must be done in parallel.
- 6. Strip back the cable on both fitting and cable run and twist the positive cables together. Then connect neutral cables together
- 7. Solder all joins using solder and either a heat gun or butane gas torch.
- 8. Cover connections using an adhesive lined heat shrink or gel cap to make connection watertight. Failure to do this will void warranty.
- Cover connections using an adhesive lined near strink or ger cap to make connect
 Heat the heat shrink or crimp the gel cap making sure all connections are covered.
- 10.Colour temperature is preset to 3000k, to change remove cover from fitting by twisting anti clockwise and set aside. Remove globe and select desired colour temperature by moving switch on side of globe and reinsert globe into lampholder
- 11. Reattach glass and then cover by turning clockwise making sure the seals are still in place and cap is tight to avoid any water penetration.
- 12. Insert fitting into canister. Apply silicon around edge of fitting to prevent any water from getting inside to electrical connections.
- 13. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

Adequate Drainage Slight decline on Ground level to allow for water to run away from fitting Light Fitting 1 Canister 100mm Space 100mm - 150mm of Crushed Bock

Steps for Installation: HV190-HC

- 1. Remove cover and glass and set aside
- 2. Insert Honeycomb lens on the inside of the glass
- 3. Reattach glass and then cover by turning clockwise making sure the seals are still in place and cap is tight to avoid any water penetration.

Steps for Changing Globe:

- 1. Remove the cover by twisting anti-clockwise then remove glass and set aside, remove globe by pulling gently.
- Re-insert the appropriate globe by aligning the 2 pins of the globes into the lampholder and pushing down gently until fimly in place. (Make sure not to exceed max wattage, see product label for correct info)
- 3. Reaftach cover by turning clockwise making sure the seals are still in place and cover is tight to avoid any water penetration.




Solid Brass fittings will naturally tarnish, Solid brass fittings with additional coatings (Antique Brass & Graphite) may tarnish through the coating when installed in outdoor environments

Must be installed by a licensed electrician

143 Beauchamp Road Matraville NSW 2036 Australia

Contact Details:

Tel: 02 9381 8300 Fax: 02 9666 8881 Email: sales@havit.com.au Web: www.havit.com.au





www.havit.com.au

