


Paso Recessed Wall Light Installation Instructions




| Product Specifications | | | | | | | | |
|------------------------|----------------------------------|------------------|-------------------------------------|-----------------|----------------------------------|------------------|-------------------------------------|-----------------|
| Model No. | HV3105T-BLK-240V | HV3105T-WHT-240V | HV3105T-BLK-12V | HV3105T-WHT-12V | HV3106T-BLK-240V | HV3106T-WHT-240V | HV3106T-BLK-12V | HV3106T-WHT-12V |
| Name | Paso | | | | Paso | | | |
| Material | Aluminium | | | | Aluminium | | | |
| Colour | Black | White | Black | White | Black | White | Black | White |
| IP Rating | IP20 | | | | | | | |
| Input Voltage | 240v AC (Remote Driver) | | 12v DC - Constant Voltage | | 240v AC (Remote Driver) | | 12v DC - Constant Voltage | |
| Protection Class | 2 (No Earth Required) | | 3 (Low Voltage - No Earth Required) | | 2 (No Earth Required) | | 3 (Low Voltage - No Earth Required) | |
| Lamp Base | Built in LED | | | | Built in LED | | | |
| Lamp Wattage | 1x 3w | | | | 1x 3w | | | |
| Colour Temp | Tri Colour - 3000k, 4000k, 5500k | | Tri Colour - 3000k, 4000k, 5500k | | Tri Colour - 3000k, 4000k, 5500k | | Tri Colour - 3000k, 4000k, 5500k | |
| Lumens | 45lm, 55lm, 49lm | | 45lm, 55lm, 49lm | | 45lm, 55lm, 49lm | | 45lm, 55lm, 49lm | |
| CRI | > 80 | | | | >80 | | | |
| Wiring | Parallel | | | | Parallel | | | |
| Dimmable | Yes | | | | Yes | | | |
| Warranty | 3 Years Replacement* | | | | 3 Years Replacement* | | | |









Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.
- All o-rings and seals must be in place correctly to maintain warranty.
- These instructions may be updated at any time due to product improvements, Please visit website for most current installation instructions.

Driver Dimensions

Steps for Installation:

- 1. Make sure that the electrical circuit is free of voltage (master switch off)
- 2. Make a hole where fitting is to be placed using dimensions provided on line drawings above.
- 3. If inserting into brick or concrete, Insert canister
- 4. 240v Models Connect the cable to LED Driver If more than one fitting installed, wiring must be done in parallel.
- 5. 12v DC Models Must be connected to 12v DC Constant Voltage LED Driver.
- 6. Strip back the cable on both fitting and cable run and twist positive cables together. Then connect neutral cables together making sure to cover connections.
- 7. Fittings are preset to 3000k, To change colour temperature slide switch located on cable to desired colour temperature.
- 3. For 240V models insert LED Driver first into hole and then
- 9. Insert fitting by squeezing clips and gently pushing fitting into cutout.
- 10. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

Must be installed by a licensed electrician

Contact Details:

143 Beauchamp Road
Matraville NSW 2036
Australia

Tel: 02 9381 8300
Fax: 02 9666 8881
Email: sales@havit.com.au
Web: www.havit.com.au

