


Nepean & Jasper Wall Light Installation Instructions




Product Specifications				
Model No.	HV3668T-BLK	HV3668T-WHT	HV3669T-BLK	HV3669T-WHT
Name	Nepean		Jasper	
Material	Aluminium			
Colour	Black	White	Black	White
IP Rating	IP54			
Protection Class	1 (240v Requires Earth) 🚇			
Input Voltage	240v AC			
Lamp Base	Built in LED			
Lamp Wattage	1x 12w			
Colour Temp	TRI Colour - 3000k, 4000k, 5500k			
Lumens	1180lm, 1320lm, 1240lm			
CRI	> 80			
Wiring	Parallel			
Dimmable	No			
Warranty	3 Years Replacement*			









Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.
- All o-rings and seals must be in place correctly to maintain warranty
- This form may be updated at any time due to product improvements, please check online installation form for most current version.

Steps for Installation:

- 1. Make sure that the electrical circuit is free of voltage (master switch off)
- 2. Loosen allen screws from side of fitting and remove cover.
- 3. Connect the cable Use wire with earth; connect the earth first, then live and neutral wire.
- 4. Install base plate to wall in desired location using appropriate screws for application.
- 5. Seal all holes including cable entry and around screws
- 6. Fitting is preset to 3000k, to change slide switch located on front PCB Panel to desired colour temperature.
- 7. Reattach fitting to base plate making sure allen screws are tight to avoid any water penetration.
- 8. Apply silicon around edge of fitting to prevent any water from getting inside to electrical connections.
- 9. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

Must be installed by a licensed electrician

Contact Details:

143 Beauchamp Road Matraville NSW 2036 Australia Tel: 02 9381 8300 Fax: 02 9666 8881 Email: sales@havit.com.au

Web: www.havit.com.au

Warranty Terms & Conditions*



