Slim Oyster Ceiling Light Installation Instructions

Product Specifications					
Model No.	HV5877T-WHT	HV5878T-WHT	HV5879T-WHT		
Name	Slim				
Material	Aluminium + Polycarbonate Diffuser				
Colour	White				
Installation Type	Ceiling - Surface Mounted				
IP Rating	IP54				
Input Voltage	240v AC				
Protection Class	2 (No Earth Required)				
Lamp Base	Built in LED				
Lamp Wattage	1x 24w	1x 30w	1x 40w		
Colour Temp	TRI Colour - 3000k, 4000k, 5500k				
Lumens	2000lm, 2100lm, 2200lm	2600lm, 2700lm, 2800lm	3600lm, 3700lm, 3800lm		
CRI	> 80				
Dimmable	Yes - Triac Dimmable				
Warranty	3 Years Replacement*				

На√іт

☐ 26

Ø503

HV5877T-WHT Dimensions HV5878T-WHT Dimensions Image: state sta

Important Safety Issues:

- This product must be installed by a qualified electrician according to AS/NZS 3000.
- Ensure all electrical mains are disconnected before any installation.
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or use of installation material that does not belong to the system.
- Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.
- All o-rings and seals must be in place correctly to maintain warranty
- If installed on surface other than ceiling eg. Wall, IP Rating downgrades to IP20.
- This form may be updated at any time due to product improvements, please check online installation form for most current version.

Steps for Installation:

- 1. Make sure that the electrical circuit is free of voltage (master switch off)
- 2. Remove base plate from fitting by twisting anti clockwise.
- 3. Insert cable through centre hole of fitting
- 4. Install base plate to ceiling in desired location using appropriate screws for application.
- 5. Connect the cable connect live and then neutral wire.
- 6. Fitting is preset to 3000k, to change slide switch located in base of fitting to desired colour temperature.
- 7. Reattach fitting to base plate making twisting clockwise until fitting is locked into place.
- 8. All connections must be carried out carefully, inspect all contacts before switching back on the electric circuit.

Must be installed by a licensed electrician

Contact Details:		Warranty Terms & Conditions*	Additional Information
143 Beauchamp Road Matraville NSW 2036 Australia	Tel: 02 9381 8300 Fax: 02 9666 8881 Email: sales@havit.com.au Web: www.havit.com.au		