## Zigbee RGBW LED Touch Panel Wall Controller





## **Product Ordering**

IMAGE	PART NUMBER	
0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0 0	HV9101-ZB-RGBWTP	TouchLink to a Zigbee Lighting Device         Step 1: Set the zigbee lighting device to start TouchLink commissioning, please refer to its manual to learn how.         Step 3: Press and hold down until LED indicator turns on.         Note: 1) Directly TouchLink (both not added to a ZigBee network), each remote can link with 30 devices.         2) TouchLink after both added to a ZigBee network, each remote can link with 30 devices.         3) For Hube Bidge & Amazon Echo Plus, add remote and devices on tetwork first then TouchLink.         4) After TouchLink, the remote can contor the linked lighting devices.

\*\* See Warranty Terms and Conditions for more information

## For more information contact Havit Lighting

ADDRESS: 143 Beauchamp Road Matraville NSW 2036 Australia 
 Tel:
 02 9381 8300

 Fax:
 02 9666 8881

 Email:
 sales@havit.com.au

 web:
 www.havit.com.au