
HV9636 Installation Instructions



Product Specifications	
Model No.	HV9636
Name	Repeater
Material	Aluminium
Colour	Black
IP Rating	IP20
Input Voltage	12v-24v DC
Protection Class	3 (No Earth Required) 🏚
LED Strip Type	Single Colour, CT, RGB, RGBC & RGBW + RGBCW
Total Load	12v = 360w 24v = 720w
Dimming Range	0.1 - 100%
Input Signal	PWM
Wiring	Parallel
Warranty	3 Years Replacement*

Important Safety Issues:


- This product must be installed by a qualified electrician according to AS/NZS 3000
- Ensure all electrical mains are disconnected before any installation.
- Modification of this product will void any warranty.
- Havit Lighting does not take responsibility for wrong installation, incorrect use, or
 use of installation material that does not belong to the system.
- Aluminium and 304SS fittings must not be installed within 5km of any salt water environments.
- Havit Lighting recommends all LED Strip components are tested before installation.
- This form may be updated at any time due to product improvements, please check online installation form for most current version.



Steps for Installation:

- Make sure that the electrical circuit is free of voltage (master switch off)
- 2. Connect Signal cable from LED Strip Controller to corresponding connection points on repeater
- If more than 1 repeater is being installed, also connect another signal cable to be connected to next repeater
- 4. Connect cable from LED Strip to corresponding connection points on repeater.
- 5. Connect LED Driver into the Power terminals on repeater
- 6. Check all connections before turning on power.

Ouput Connections



- (1) Y channel load output
- (12) W channel load output
- (13) B channel load output
- (14) G channel load output
- (15) R channel load output
- (6) Load output (+)
- (17) Power supply input voltage (+)
 - 18 Power supply input voltage (-)

Must be installed by a licensed electrician

Contact Details:

143 Beauchamp Road Matraville NSW 2036 Australia

Tel: 02 9381 8300 Fax: 02 9666 8881 Email: sales@havit.com.au Web: www.havit.com.au


Warranty Terms & Conditions*














Must be installed by a licensed electrician

Contact Details:

143 Beauchamp Road Matraville NSW 2036 Australia

Tel: 02 9381 8300 Fax: 02 9666 8881 Email: sales@havit.com.au Web: www.havit.com.au

Warranty Terms & Conditions*





