OPERATION INSTRUCTION LED LIGHTHEAD

Specifications



• Do not install and/or operate this safety product unless you have read and understand the safety information contained in this manual.

Page 1 of 2

This document provides all the necessary information to allow your product to be properly and safely installed. Before beginning the installation and operation of your new product, the installation technician and operator must read this manual completely.

Installation Instruction

- Read all safety notes and mounting guidelines before installing the product. Verify that all parts listed under "In the Box" are present and complete. (Picture 1)
- Verify that all power supply comply to the specified voltage limits for the light.



Wiring Instruction

To +VDC (Fuse @ 3A)RED
To Chassis GroundBlack
For SynchronizationYellow
For AsynchronizationGreen

Wiring 2 or more lights to synchronize:

- All Red wires to positive (+)
- All Black wires to groud (-)
- All Yellow wires must be tied together and touch to "+ "to change patterns

NOTE for synchronizing:After attaching all wires, (turn on power) touch

and hold yellow wires to " + "for 3-4 seconds and all lights will go out for one second and then come back on. They are now synchronized and every time you touch yellow wire to "+ ", it will change the pattern on all lights.

Wiring 2 or more lights to "wig-wag" asynchronization :

 Follow instructions for synchronizing and then attach one green wire to power and lights will wig-wag back and forth. You can still change patterns in this mode by touching yellow wire to "+".



Important! This unit is a safety device, and it must be connected to its own separate, fused power point to assure its continued operation should any other electrical accessory fail.

Page 2 of 2