


# FLOOR SCALE ASSEMBLY GUIDE



- 1.** Carefully open box and remove scale
- 2.** Locate compartment (found on side of scale) and remove the screws
- 3.** Remove all contents - indicator cable, power cable, manual and indicator bracket  
*NOTE: Indicator will be shipped separately*
- 4.** Feet will be in a bag on the underside of the scale (between frames)
- 5.** Screw feet into the load cells until scale is leveled  
*NOTE: Do not screw in too deep that it will touch the platform*
- 6.** Place scale on flat surface and make sure scale is stable
- 7.** Route the indicator cable inside the compartment through an available opening (inside compartment) and connect to the indicator
- 8.** Close compartment latch with screws
- 9.** Connect the indicator and power on
- 10.** Once indicator is powered on, display will count down and be zeroed out (no calibration needed). Scale is ready for use
- 11.** If indicator does not count down and zero out, calibration will be needed (please refer to manual for proper calibration steps)

Please call **(844) 735-5386** for support questions

For updated indicator manual, please refer to [www.selletonscales.com](http://www.selletonscales.com) "Downloads"