



**INSTALLATION  
MANUAL**

Load cell Feet

Label printers  
bracket screws

Outer tower bolts



Scoreboard  
bracketbolt

Inner tower  
bolts



**1**

Start unpacking the protective Frame of the Wrapping machines


**2**

Use the forklift channels to pick the wrapping machine up & remove it from Crate.



**3**

Set the wrapping machine on the ground



**4**

Lift up the tower with 2-3 people or use a forklift & strap

**5**


Remove the Engine Cover by unscrewing the bolts



**6**

Remove the Side panel on the tower by removing the screws






**7**

Locate the anchoring holes

**8**


Install the 2 bolts



**9**

Install the 2 bolts located on to the left side of the machine, on each side of the stretch wrap





**10**

Install the Bolt on top of the tower to hold the bracket & the scoreboard

**11**

Plug in the Power & the 5 prong scoreboard cables



**12**

Install the Bracket for the printer & plug in the printer & power cable



**13**

Install all 4 feet  
& Screw all the way up

**14**

Place the stretch wrap film on to  
the pole system & feed it as  
shown in the below diagram

