

COSMIC ROMANCE

The following set of diagrams shows you step by step how to fold your tent when packing it away. The small tabs shown on the circumference of the tent illustration represent the black tabs which you use to peg the ground sheet down. The distance from one tab to the next is roughly the length of the carry bag your tent comes with. With this in mind, you want to end up with a rectangle shape that is the same length or shorter than your bag.

*Hot Tip! This process is made easier by first expelling all air from inside the tent.

Make sure before you begin folding that all zips are done up, including windows, doors and the ground sheet. Also ensure there is no moisture on the tent as this can lead to the growth of mildew. Sweep out any dirt from inside the tent floor as well, as this can lead to bad odours. If the pegs are covered in mud/dirt, give them a wipe before packing away, as this can cause them to rust. The cleaner the tent is when you pack it away, the nicer it will be to camp in the next time you use it!

















