



SIT - IN KAYAKS

EXPEDITION ZERO, 1, 2, 3



New SmartTrack Hybrid Foil.
Split pin to hold rudder secure.

AQUANAUTA PRO



New SmartTrack Hybrid Foil.
No split pin - just 90 degree rotate to secure.

AQUANAUTA, AQUANAUTA XL



Standard Rudder (not spring loaded).
No split pin - just 90 degree rotate to secure.

DREAMER, DREAMER XL, HUG XL



New SmartTrack
No split pin - just 90 degree rotate to secure.

HUG



Aluminum rudder
Insert the stainless steel strip into the hole in the tail of the kayak and connect the rudder with 2 black nylon ropes
Split pin to hold rudder secure

HOW TO
INSTALL
RUDDER?

SIT - ON - TOP KAYAKS

PERCH ANGLER 3.3M



Aluminum rudder

Insert the stainless steel strip into the hole in the tail of the kayak and connect the rudder with 2 wire ropes
Split pin to hold rudder secure

PEDAL PRO FISH 3.4M



Aluminum rudder

Insert the stainless steel bar into the hole of the iron block and connect the rudder with 2 steel ropes
Split pin to hold rudder secure

PEDAL PRO FISH 3.2M



Standard Rudder
(not spring loaded).
Split pin to hold rudder secure

PEDAL PRO FISH PRO XL



Standard Rudder
(not spring loaded).
Split pin to hold rudder secure

ANGLER PRO, ANGLER PRO XL



Standard Rudder
(not spring loaded).
Split pin to hold rudder secure.