




**1** Use the iron wire to pull the controller through the square hole.

**2** Pull the controller from the round hatch.

**3** Install the controller and secure the screws.



**4** Pull the cable left and right to ensure a smooth rotation and the correct direction of the manual handle.

**5** Thread the cable through the butterfly screws and fixing bolt.

**6** Press tight the fixing bolt.

**7** Attach the butterfly screws to the stern rudder.