


Assembly Directions for Octagon Picnic Table

Model #POPT-5184

Step 1 Place the four (4) seat/leg sections in a square as shown.




Step 2 Locate the stainless steel plate in your hardware package, align ends of opposite seat/leg sections with plate (as shown), and fasten plate using 1" screws. This will tie all four sections together.



Step 3 Place the table top on the seat/leg sections. Then fasten top using one (1) $\frac{5}{16}$ " x 2" Allen Head bolt per leg (upright).



Step 4 Enjoy your completed picnic table!



Use to measure bolts

PACKAGE CONTENT

- 1 Top
- 4 Legs
- 1 Metal Plate
- 1 Hardware Package

Tools Needed:

- Hammer,
- Screw Gun,
- $\frac{1}{2}$ " Wrench
- Allen Wrench (Included)

HARDWARE PACKAGE

- 24 1" Screws
- 4 $\frac{5}{16}$ " x 2" Allen Head Bolts
- 4 $\frac{5}{16}$ " Flange Nuts
- 1 Allen Wrench

