SLOAN BEDPAN WASHER

TROUBLESHOOTING & MAINTAINING THE BEDPAN WASHER

1 PROBLEM: DIVERTER LEAKING AT SPRAY ARM

SOLUTION: A) Diverter spray arm (old style) is damaged. Replace diverter arm with new spray arm replacement kit. NOTE: On old style diverter soray arm, the soray arm O-ring was placed on groove at the end of the spray arm. When installing new spray arm kit. place washer into bottom of hole of nozzle pivot Then place the O-ring on ton of washer Insert new

spray arm into the pivot, pressing in slightly. While holding spray arm in place, tighten set screw. B) Spray arm O-ring is damaged or installed improperly. Re-install O-ring as described above in step (A). If leakage persists replace using spray

arm kit DV-1007-A (#08846). 2 PROBLEM: DIVERTER LEAKING AT NOZZLE PIVOT

SOLUTION:

- A) One or both pivot O-rings are worn. Replace nozzle pivot assembly. Use pivot replacement kit.
- B) Diverter seal washer worn or missing. Replace nivnt seals. Use diverter rebuild kit C) Nozzle pivot damaged or defective. Replace nozzle

pivot assembly. Use pivot replacement kit. FRRATIC SPRAY PATTERN FROM ARM NOZZI F

SOLUTION: A) Debris clogging nozzle screen. Wash nozzle screen

3 PROBLEM-

- under running water. B) Damaged or missing nozzle screen or spray disc. Replace using DV-1007-A (#08846) spray arm
- replacement kit 4 PROBLEM: DEOSEPTIC SOLUTION NOT SIPHONING FROM BOTTLE DURING FLUSH CYCLE
 - (DEOSEPTIC MODELS ONLY) SOLUTION: A) Adjusting screw not open. Open adjusting screw until adequate amount of solution is siphoned from

bottle during flush cycle

- B) Aspirator tube screen cloqued. Remove the solution bottle. Remove aspirator tube from the swivel & ball check assembly and wash the screen under running water.
- C) Aspirator tube not installed completely onto swivel & ball check assembly. Remove solution bottle Make sure aspirator tube is pushed completely onto
- nipple of swivel & hall check assembly. D) Aspirator tube cracked. Replace aspirator tube
 - E) Rubber ball check stuck inside swivel & ball check assembly. Remove solution bottle and aspirator tube from swivel & ball check assembly. Gently insert small implement (paper clip, small dia, hex key, etc.) into nipple of swivel & ball check assembly to dislodge rubber ball check. Stop pushing once water starts to trickle from nipple NOTE: If ball is pushed too hard or too far it may fall out of seat. Should this occur, the swivel & ball check assembly must be removed and ball replaced. To do this, remove retaining ring using

to drop rubber ball check. Place rubber ball back into seat of swivel & ball check assembly and reassemble. If ball and seals appear worn rebuild

5 DDODLEM: WATER LEAVING DACK INTO COLUTION POTTLE

- SOLUTION: A) Rubber ball damaged or missing. Replace rubber hall using DV-1004-A (#08095) deosentic diverter rebuild kit B) Rubber ball is not sitting in seat of swivel & ball
 - check assembly. Bemove swivel & ball check assembly, taking care not to lose rubber ball. Insert rubber ball back into seat of swivel & ball check assembly and reassemble. NOTE: Follow steps in solution (E) of problem 4.

CARE AND CLEANING OF CHROME AND SPECIAL FINISHES

DO NOT use abrasive or chemical cleaners to clean flushometers as they may dull the luster and attack the chrome or special decorative finishes.

Use ONLY mild soap and water, then wipe dry with clean cloth or towel. While cleaning the hathroom tile, the flushometer should be protected from

any splattering of cleaner. Acids and cleaning fluids can discolor or remove the chrome plating

CALL FOR TECHNICAL ASSISTANCE!