



ELECTRONIC FAUCET PARTS

Toll Free: 800-442-6622
Pittsburgh: 412-781-9100
Phone Hours: Mon-Fri: 8am-5:00pm

EBF-650 EBF-615



#32740
Four "C"
Batteries
Required



#32737
Four "AA"
Batteries
Required

1A	#54700	EBF120A	Pedestal Faucet Spout & Sensor Assembly (EBF-615)
1B	#54701	EBF81A	Faucet Spout & Sensor Assembly (EBF-650)
2	#59173	ETF1023A	Spray Head w/Key (male 0.56 gpm)
	#54683	ETF1024A	Aerator Spray Head w/Key (male 2.2 gpm)
	#85444	ETF1029A	Laminar Flow Aerator (male 2.2 gpm)
3	#54693	ETF435	Key Only
4A	#54703	EBF123A	Mounting Kit for EBF-615
4B	#54678	MIX101A	Mounting Kit for EBF-650
5A	#54685	ETF547	1/8" NPT Pipe to 3/8" Compression
5B	#56794	ETF617A	3/8" Bak-Check® Tee
5C			Solenoid Supply Kit (NOT SOLD)

6	#54325	EBF60A	Old Style Control Module Assy. Uses Four "C" Batteries (#32740) & Five Pin Connector
6A	#54335	EBF1011A	Old Style Solenoid Replacement Kit includes Solenoid Body, Solenoid Enclosure, and Solenoid Filter Cap.
6B	#08578	EBF1004A	Old Style Solenoid Valve Module Assembly for Transformer Powered mode (-R variation). Includes Solenoid Enclosure, Solenoid Body, and Filter Cap.
7	#54686	EBF79A	Mounting Hardware
8	#57970	EBF80A	Old Style Sensor Replacement Kit includes Cable Assembly, Retainer for PC Board Assembly, and Housing for Sensor Window
9	#81784	ETF740A	New Style Solenoid Assembly
10	#81785	ETF735A	New Style Control Module Assy. Uses Four "AA" Batteries (#32737) & Phone Jack