

Installation Instructions

1. Close the sliding gate.
2. Position the brushes 100mm from the outside of either wheel.
3. Make sure that the brushes do not make contact with the end stops when the gate is open or closed.
4. Make sure that the brushes are making contact in either side in the gate track.
5. Mount the brushes on the gate frame.