

How to Write?

This pen changes the traditional grip and therefore it's necessary you keep this in mind:

Correct Grip!



Inorrect Grip!



Place the underside of the thumb in the hollow in the pen and lay your index finger along the pen. Do not press with your index or middle finger

Avoid a pinching or precision grip, which will rapidly tire your hand.

REMEMBER

Replace the Parker rollerball refill with another of the same quality. Please do not use a ballpoint refill instead, this will add stress to your writing