

How to Use?

- Unpack the scissors and remove the safety cover. Please retain it safely for later use during storage
- Hold the scissors with your left hand, putting the thumb through the loop of the inner blade and your middle finger through the other loop.
- Place your index finger below the loop of the middle finger to provide guidance and control
- Cut in standard motion as you would normally
- Once done, please store the scissors safely after putting on the Blade Guard

- Do clean the scissors carefully with a soft brush and slightly damp cloth



REMEMBER

- Please do not press down excessively or beat down on the handles in case the material you are trying to cut does not give way

- The blades must not be exposed to water for too long - kindly ensure you dry them thoroughly before storing
- Store it in a cool and dry place to extend the life of the blades and handles